
ESL-TR-89-04



SUBSTITUTION OF WAX AND GREASE CLEANERS WITH BIO-DEGRADABLE SOLVENTS: PHASE I, PART II

P.M. WIKOFF, R.K. SCHOBER, T.L. HARRIS, D.F. SUCIU, R.E. McATEE, G.S. CARPENTER, P.A. PRYFOGLE, J.M. BELLER

EG&G IDAHO, INC. P. O. BOX 1625 IDAHO FALLS ID 83415

SEPTEMBER 1989

FINAL REPORT

OCTOBER 1987 — SEPTEMBER 1988

S DTIC ELECTE JUN 1 1 1993

APPROVED FOR PUBLIC RELEASE: DISTRIBUTION UNLIMITED

93-13102





AIR FORCE ENGINEERING & SERVICES CENTER ENGINEERING & SERVICES LABORATORY TYNDALL AIR FORCE BASE, FLORIDA 32403

<u>NOTICE</u>

PLEASE DO NOT REQUEST COPIES OF THIS REPORT FROM HQ AFESC/RD (ENGINEERING AND SERVICES LABORATORY).

ADDITIONAL COPIES MAY BE PURCHASED FROM:

National Technical Information Service 5285 Port Royal Road Springfield, Virginia 22161

FEDERAL GOVERNMENT AGENCIES AND THEIR CONTRACTORS
REGISTERED WITH DEFENSE TECHNICAL INFORMATION CENTER
SHOULD DIRECT REQUESTS FOR COPIES OF THIS REPORT TO:

Defense Technical Information Center Cameron Station
ALEXANDRIA, VIRGINIA 22314

| iΕ | CURI | TYC | LAS | SIFICA | TION C | F THIS | PAGE |
|----|------|-----|-----|--------|--------|--------|------|

| SECURITY CLASSIFICATION OF THIS PAGE | | | | | | | |
|--|--|--|---|----------|--------------------------|----------------|--|
| REPORT (| N PAGE | | | 1 | Approved No 0704-0188 | | |
| 1a. REPORT SECURITY CLASSIFICATION | 16 RESTRICTIVE | MARKINGS | ~ | <u> </u> | | | |
| UNCLASSIFIED | • | | | | | | |
| 2a. SECURITY CLASSIFICATION AUTHORITY | | 3. DISTRIBUTION/AVAILABILITY OF REPORT | | | | | |
| 2b. DECLASSIFICATION/DOWNGRADING SCHEDU | LE | Approved for public release. Distribution unlimited. | | | | | |
| 4. PERFORMING ORGANIZATION REPORT NUMBE | R(S) | 5. MONITORING | ORGANIZATION R | EPORT N | UMBER(S) | <u></u> | |
| · | • | | - · · · · · | | , | | |
| ESL-TR-89-04 | | <u> </u> | | | | | |
| 68. NAME OF PERFORMING ORGANIZATION | 66. OFFICE SYMBOL | 7a. NAME OF MO | 7a. NAME OF MONITORING ORGANIZATION | | | | |
| EG&G Idaho, Inc | (If applicable) | | Air Force Engineering and | | | | |
| | Chem Science | Services Center | | | | | |
| 6c. ADDRESS (City, State, and ZIP Code) | | 76. ADDRESS (Cit | y, State, and ZIP (| Code) | | | |
| P.O. Box 1625 | | HQ AFESC | 'RDVS | | | | |
| Idaho Falls ID 83415 | | Tyndall A | AFB FL 32 | 403-6 | 001 | | |
| 8a. NAME OF FUNDING/SPONSORING | 86. OFFICE SYMBOL | 9 PROCUREMENT | INSTRUMENT ID | ENTIFICA | TICN NUN | ARER | |
| ORGANIZATION | (If applicable) | | | | | | |
| | | Contract | # DE-ACO7 | -76ID | 01570 | | |
| Bc. ADDRESS (City, State, and ZIP Code) | | 10. SOURCE OF FUNDING NUMBERS | | | | | |
| | | PROGRAM | PROJECT | TASK | | WORK UNIT | |
| | | ELEMENT NO. | NO. | NO | 1 | ACCESSION NO | |
| | | 63723F | 2054 | 71 | | 04 | |
| 11. TITLE (Include Security Classification) | Substitution | of Wax and | Grease C | leane | rs wit | -h | |
| Biodegradable Solvents, Ph | nase I Report | (UNCLASSIF) | ED) PART | II | | | |
| 12. PERSONAL AUTHOR(S) P.M. WIKOFF, | R.K. Schober | , T.L. Harr | is, D.F. S | Suciu | , R.E. | McAtee, | |
| G.S. Carpenter, P.A. Pryfo | | | | | | | |
| | 0/87 TO 9/88 | 14. DATE OF REPO | KI (Year, Month, 1000 | יון (ענט | 5 PAGE C | OUNT | |
| 16. SUPPLEMENTARY NOTATION | 70. 0 _ 37.00 | 3eptember | 1909 | | 764 | | |
| | | • | | | | | |
| Availability of this report | t is specifie | d on revers | e of front | t cove | er. | | |
| 17. COSATI CODES | 18. SUBJECT TERMS (| Continue on reverse if necessary and identify by block number) | | | | | |
| FIELD GROUP SUB-GROUP | solvents, c | leaners, halogenated, hydrocarbon, | | | | | |
| 7 02 | biodegradabl | e, industri | al wastewa | ater, | hazar | dous | |
| | waste minimi | | | | | | |
| 19. ABSTRACT (Continue on reverse if necessary Methods have been tested i | and identify by block no or systematic | _{umber)} _evaluation | s of biode | egrada | ahle s | :olvents | |
| for aircraft parts cleaning | g, degreasing | , and maski | ng-wax rem | noval | proce | esses. | |
| Screening tests have ident | ified solvent | s that are | biodegrada | able. | can | | |
| efficiently remove soils from aircraft parts in a dip tank, and meet the | | | | | | | |
| military specification req | mirement for a | corrosivene | ss (ANSI/A | ASTM) | in pr | cocesses | |
| used at the five Air Force | Air Logistic | s Centers (| ALCs). Th | ne dat | tabase | ! | |
| developed during Phase I, of this program identifies each process, the | | | | | | | |
| chemicals used, tank volumes, testing requirements, and alternative chemicals. | | | | | | | |
| To test solvent biodegrability, an ASTM method was modified and used to test a bench-scale activated sludge system by measuring chemical oxygen demand (COD) | | | | | | | |
| and adenosine triphosphate (ATP) over a 6-hour period to determine if the | | | | | | | |
| bacteria will reduce COD to below the limit established by the National | | | | | | | |
| Pollution Discharge Elimination System (NPDES). Solvents were categorized to | | | | | | | |
| identify any trends, and s | ix were selec | ted for in- | depth pilo | t-sca | ile te | sting. | |
| 20. DISTRIBUTION/AVAILABILITY OF ABSTRACT UNCLASSIFIED/UNLIMITED SAME AS | RPT DTIC USERS | 21. ABSTRACT SE UNCLASSIF | CURITY CLASSIFIC | ATION | | | |
| 224 NAME OF RESPONSIBLE INDIVIDUAL 22b TELEPHONE (Include Area Code) 22c. C | | | | | | MBOL C/RDVS | |
| D Form 1473 IIIN 96 | | | | | | | |

Previous editions are obsolete.

PREFACE

This report was prepared by Idaho National Engineering Laboratory, EG&G Idaho, Inc., P.O. Box 1625 Idaho Falls, Idaho 83415 under Contract Number DE-AC07-76ID01570 for the Air Force Engineering and Services Center (AFESC), Tyndall Air Force Base, Florida 32403-6001. Mr Charles J. Carpenter was the Government technical program manager. This report summarizes work accomplished between 1 October 1987 and 30 March 1989.

This report has been reviewed by the Public Affairs Office and is releasable to the National Technical Information Service (NTIS). At NTIS it will be available to the general public, including foreign nations.

This technical publication has been reviewed and is approved for publication.

CHARLES J. CARPENTER

Project Officer

KENNETH T. DENBLEYKER, Maj, USAF Chief, Environmental Sciences

Branch

PRANK P. GALLACHER, Colonel, USAF Chief, Environics Division

JAMES R. VAN ORMAN

Deputy Director

Engineering and Services Laboratory

| Accesion For | | | | | | |
|---|--|--|--|--|--|--|
| NTIS CRA&I DTIC TAB Unannounced Justification | | | | | | |
| By | | | | | | |
| Availability Codes | | | | | | |
| Dist Avail and or Special | | | | | | |
| A-1 | | | | | | |

DITC QUALITY INSPECTED 2

APPENDIX A

DETAILED BIODEGRADABILITY PROTOCOL

APPENDIX A

DETAILED BIODEGRADABILITY PROTOCOL

The following pages contain the detailed procedures followed for testing solvents for biodegradation in an activated sludge system.

A. TEST CONFIGURATION

The activated sludge from Tinker AFB is maintained in a culture column with air circulation, with siphon activated maximum volume overflow wasting, and with constant nutrient additions. Solids are maintained at approximately 2.5 grams/liter. The test configuration (columns) is shown in Table A-1 below.

TABLE A-1. TEST CONFIGURATION

| Time <u>(hours)</u> | 1 | 2 | 3 | Test Col | umns 5 | 6 (Phenol) |
|------------------------|--------------------------------------|------------|------------|------------|------------|------------|
| 0 | 2F ^a 2ATP ^b | 2F 2ATP | 2F 2ATP | 2F 2ATP | 2F 2ATP | 2F 2ATP |
| 1 | 2F 2UF ^C | 2F | 2F | 2F | 2F | 2F |
| 2 | 2F | 2F | 2F | 2F | 2F | 2F |
| 3 | 2F | 2F | 2F | 2F | 2F | 2F |
| 4 | 2F | 2F | 2F | 2F | 2F | 2F |
| 5 | 2F 2UF | 2F | 2F | 2F | 2 F | 2F |
| 6 | 2F 2ATP | 2F 2ATP | 2F 2ATP | 2F 2ATP | 2F 2ATP | 2F 2ATP |

a. 2F = 2 filtered (2-mL) samples for COD analysis.

B. SOLIDS

Activated sludge, brought to this lab from Tinker AFB's IWTP, is concentrated by centrifugation at 5° C and 5000 rpm. The elutrient is discarded and the pellet is collected in a container which is stored in a refrigerator at 5° C. The moisture content of the concentrated sludge is determined by adding 1.0 grams of wet concentrated sludge to a

b. 2ATP = 2 unfiltered (1-mL) samples for-adenosine triphosphate.

c. 2UF = 2 unfiltered (2-mL) samples for COD analysis.

preweighed pan. The material is dried to a constant weight at 105° C in a drying oven. The percent of solids is determined by:

This value is used to determine the amount of concentrated sludge added to the column.

C. COLUMN SETUP

_ - 1

- o Four liters of dilution medium is added to the column, and air agitation is turned on.
- Agitation is continued for 5 minutes to permit mixing and oxygenation of the solution prior to the addition of solids.
- o The preweighed solids are added to the column.
- Nutrient feed is started to the column.
- o Following 1/2 hour mixing period, a 50 mL sample is pulled in a glass beaker, a magnet bar is added, and the sample is placed on a stirring plate. The pH of the solution is measured using a calibrated pH probe. This solution is then discarded.
- o A 25 mL sample of the culture column material is added to a preweighed drying tin. The sample is placed in a 105°C drying oven and dried to a constant weight.

Comments:

The air flow in the column should be adjusted to prevent excessive bumping, but adequate mixing.

Check all feed and waste discharge lines for proper flow.

Prepare a slide for microscopic observation of the column material.

D. DILUTION MEDIUM

The EPA nutrient medium used for maintaining the activated sludge is made of the following materials (see Table A-2).

- 1 liter deionized water (DIW)
- 1 milliliter solution I
- 1 milliliter solution II
- 1 milliliter solution III

TABLE A-2. DILUTION MEDIUM COMPOSITION

| Solution | Compound | g/L |
|----------|--|---------|
| I | NH4C1 | 35 |
| | KNO ₃ | 15 |
| | K ₂ HPO ₄ ·3H ₂ O | 75 |
| | NaH ₂ PO ₄ H ₂) | 25 |
| 11 | кс1 | 10 |
| | $MgSO_4$ | 20 |
| | FeSO ₄ ·7H ₂ O | 1 |
| | (adjust pH to 3.0) | |
| III | CaC1 ₂ | 5 |
| | ZnC1 ₂ | 0.05 |
| | MnC1 ₂ ·4H ₂ O | 0.5 |
| | CuCl ₂ | 0.05 |
| | CoCl ₂ | 0.001 |
| | H ₃ BO ₃ | . 0.001 |
| | Mo0 ₃ | |

^{*}Federal Register (September 27, 1985), volume 50, number 188, page 39279. Refrigerate the solutions.

E. NUTRIENT SUPPLEMENT PREPARATION

. :

The following addresses the nutrient feed solution of phenol, nitrogen, and phosphorus added daily. The ratio of 10:5:1 (C:N:P) is the operating premise. Iron is added as an additional supplement for good floc growth.

The average phenol feed is assumed to be 100 ppm (similar to pilot plant maintenance feed requirements). The feed rate of 16 L per day would offer a 4.0 turnover rate of the column (4 L volume), similar to the pilot plant and IWTP at Tinker AFB.

```
100 ppm - carbon, (100 mg/liter)(16.0 liters) = 1.60 g C/day

50 ppm - nitrogen, (50 mg/liter)(16.0 liters) = 0.80 g N/day

10 ppm - phosphorus, (10 mg/liter)(16.0 liters) = 0.16 g P/day

5 ppm - iron, (5 mg/liter)(16.0 liters) = 0.08 g Fe/day
```

For the source of carbon, phenol is added at a rate of <u>1.60 grams of phenol</u> daily.

Ammonium chloride (NH₄Cl) is used as the source of nitrogen. The nitrogen in ammonium chloride represents approximately 26% of the formula weight; therefore, (0.8 grams N/Day)/(26% N/NH₄Cl) = 3.077-qrams NH₄Cl/day is required in the nutrient feed.

Potassium phosphate (KPO₄) is used as the source of phosphorus. The phosphorus in potassium phosphate represents approximately 13% of the formula weight; therefore, (0.16 grams P/day)/(13% P/KPO₄) = $\frac{1.231\text{-grams}}{\text{KPO}_4/\text{day}}$ is required in the nutrient feed.

Ferric Chloride (FeCl₃) is used as the source of iron. The iron in ferric chloride represents approximately 34.5% of the formula weight; therefore, $(0.08\text{-grams Fe/day})/(34.5\% \text{ Fe/FeCl}_3) = \frac{0.232\text{-grams /FeCl}_3}{1000}$ is required in the nutrient feed.

F. FEED/FLOW RATE CALCULATIONS

Based on a feed flow rate of 0.75 mL/min, the amount of materials needed to be in a liter of the biodegradation solution can be calculated by:

(0.75 mL/min)(60 min/hour)(24 hours/day) = 1080 mL/day, or 1.08 Liters/day

Therefore, in making up the nutrient feed for the columns, the following compounds must be added in the amount indicated.

| Volume | | Ammonium | Potassium | Ferric |
|----------|---------|----------|-----------|----------|
| Prepared | Pheno1 | Chloride | Phosphate | Chloride |
| (liters) | (grams) | (grams) | (grams) | (grams) |
| 1 | 1.481 | 2.849 | 1.140 | 0.215 |
| 2 | 2.962 | 5.698 | 2.280 | 0.430 |
| 3 | 4.443 | 8.547 | 3.420 | 0.645 |

- The ammonium chloride, potassium phosphate (monobasic), and ferric chloride are added to the basic nutrient media.
- o The solution is sterilized, 121°C, 20 psi, 20 minutes
- o The solution is cooled to room temperature, and
- o The phenol additive is prepared by:
 - a) dissolve phenol in 50 mL of deionized water
 - b) filter sterilize.
- o Add the phenol to the media.
- The nutrient media is attached, aseptically, to the nutrient feed pump.

G. TEST SET-UP PROCEDURES

During the biodegradation test, the basic EPA nutrient medium is used to dilute the solvent and culture material in the test columns.

The test columns are filled to a total volume of about 250 mL's

- o 0.417 mL of most concentrated manufacturer's recommended mix of solvent (based on a 1:600 dilution, which is a typical IWTP dilution ratio at Tinker AFB)
- o 225 mL's of solvent and basic EPA nutrient media (appropriate dilution, concentration).
- o 25 mL's of culture column microorganisms

COD determinations are run according to HACH Chemical procedures.

ATP determinations are run according to the internal standard method of Turner Instruments. Inc.

2 mL samples are filtered using a syringe-filter system equipped with a 0.45 micron pore-size filter.

Dry weights are determined on the culture column and initial samples at the beginning and end of the test runs. Twenty-five mL samples of material are placed in a preweighed drying pan which is placed in a drying oven (103°C) until the sample is dry. The pan is reweighed, and the difference between the initial and final pan weights divided by the volume placed in the drying pan gives solid dry weights per unit volume.

COD values are compared to a control phenol column run simultaneously during each test period.

Also, COD values are compared to each other based on solid dry weights. ATP, and relative phenol degradations.

H. ATP PROCEDURE

Set ATP Photometer: 3-second delay, 10-second integration period

Reading Unknown (RU)

- 1. 50-ωL sample in 8 X 50 mm polypropylene tube
- 2. Add 50 wL releasing agent, mix, and let stand 30 seconds
- 3. Add 50 wL HEPES buffer
- 4. Place in photometer
- 5. Inject 100 ωL Luciferin-Luciferase (L&L)
- 6. Record full integral

Reading Internal Standard (RIS)

- 1. 50-ωL sample in 8 X 50 mm polypropylene tube
- 2. Add 50 wL Releasing Agent, mix, and let stand 30 seconds
- 3. Add 50 wL ATP Standard, 2.5-E-2uG/mL ATP
- 4. Place in photometer
- Inject 100 ωL Luciferin-Luciferase (L&L)
- 6. Record full integral

Reading the Blank (RB)

- 1. 50-ωL sample in 8 X 50 mm polypropylene tube
- 2. Add 50 wL releasing agent, mix, and let stand 30 seconds
- 3. Add 50 wL HEPES buffer
- 4. Place in photometer
- 5. Inject 100 wL Luciferin-Luciferase (L&L)
- 6. Record full integral

Reagents

Releasing Agent - purchased, ready-to-go from Turner Designs, Inc. HEPES buffer - purchased, ready-to-go from Turner Designs, Inc.

ATP Standard - purchased as a concentrated, sterile liquid from Turner Designs, Inc., see the following page for preparation details

Luciferin-Luciferase - purchased as a sterile, dry powder (5.5 mL preparation volume) from Turner Designs, Inc., see the following page for preparation details

KEEP ALL REAGENTS REFRIGERATED AND COOLED

ATP STANDARD SHOULD BE FROZEN BETWEEN TESTING PERIODS

DISCARD ANY THAWED L&L FOLLOWING THE DAILY TEST PERIOD

ATP STANDARDS PREPARATION

- 1. Fill dewar with liquid nitrogen.
- 2. Calibrate 100- ω pipet (Eppendorf) to deliver 25 ω L, by weight using the microbalance, 0.2500 grams/10 deliveries.
- 3. Use a 10-mL volumetric pipet to deliver 10-mL of sterile HEPES buffer into five clean plastic tubes.
- Pipet 25 ωL of ATP Standard (5-mL bottle, blue label, liquid, Turner Designs) into each 10-mL tube.
- 5. Vortex mix each tube following the addition of the ATP Standard.
- 6. Pipet 2 mL of the diluted standard into blue, snap cap tubes.
- 7. Place the 2 mL ATP Standards in the liquid nitrogen.
- 8. Continue steps 5 8 until the five test tubes of HEPES buffer have been used.
- 10. Remove the prepared standards from the liquid nitrogen and place them in a labeled beaker (indicating the date of preparation and the people who prepared them) and place the beaker in the freezer.

J. LUCIFERIN-LUCIFERASE PREPARATION

- 1. Remove 5 or 6 bottle s of L&L (green labels, Turner Designs) from the refrigerator.
- 2. Using a 10-mL syringe (calibrated to 0.2 mL volume), add 5.5 mL of sterile HEPES buffer to 3 of the bottles of L&L.
- Using a 1 mL pipet, transfer 1 mL of the L&L into a blue, snap-cap, conical plastic tube.
- 4. Close the cap and place the tube in liquid nitrogen.
- 5. After all of the bottles have been made up, remove the prepared L&L tubes from the liquid nitrogen and place them in a labeled beaker (indicating the date of preparation and the people who prepared them) and place the beaker in the freezer.

K. COD STANDARD PREPARATION

Do not add dry chemical or strong acid/base to a dry volumetric flask; therefore, add approximately 10 mL of nanopure water to 3-100 mL volumetric flasks.

Mark one of the three volumetric flasks as number "1". This is the initial solution flask. Mark the other two flasks as "A" and "B". These will be the two standards, actually measured.

1. Initial Solution

- o Weigh out 9.80 grams of ferrous ammonium sulfate (FAS) and add this to the volumetric flask.
- o Using a 2-mL volumetric pipet, transfer 2 mL of concentrated sulfuric acid to the volumetric flask.
- o Bring the volume in the volumetric flask to about 3/4 total volume.
- o Swirl the flask until all of the FAS crystals have dissolved.
- o Bring the flask volume to the mark with nanopure water and seal with parafin
- o Invert the volumetric at lest 13 times, allowing the neck to fill and empty completely each time (rotate the flask slightly each inversion also).

2. Standard Solution A

- o Using the Solution 1, fill a 10-mL volumetric pipet to just above the mark.
- o Empty the pipet into a large volume waste beaker.
- O Draw a second volume of a solution to the mark and transfer this volume to the volumetric flask labeled "A".
- o Fill the volumetric flask to the mark with nanopure water, seal with parafilm, and invert at least 13 times (same as making the initial solution).
- o Rinse a small, clean, plastic weigh boat with this solution.
- o Discard the rinse into the waste beaker.
- Fill the weigh boat again with this solution and transfer2 mL's of this solution to two separate COD analysis tubes.
- o Vortex the tubes and place them in the COD incubator.

3. Standard Solution B

Using Solution 1, fill a 25-mL volumetric pipet to just above the mark.

Empty the pipet into a large volume waste beaker.

Draw a second volume of a solution to the mark and transfer this volume to the volumetric flask labeled "B".

Fill the volumetric flask to the mark with nanopure water, seal with parafilm, and invert at least 13 times (same as making the initial solution).

Rinse a small, clean, plastic weigh boat with this solution.

Discard the rinse into the waste beaker.

Fill the weigh boat again with this solution and transfer 2 mL of this solution to two separate COD analysis tubes.

Vortex the tubes and place them in the COD incubator.

NOTES:

When you are through with the solutions prepared for COD analysis:

- a. Discard remaining solutions into the waste solution beaker.
- b. Add an equal amount of water to dilute the acidic solution.
- c. Neutralize and discard this solution (it is only an iron precipitate).
- d. Rinse the volumetric flasks (fill and dump) three times with tap water.
- e. Wash the outside of the volumetric flasks with soap and hot water.
- f. Rinse the volumetric flasks (fill and dump) three times with tap water.
- g. Rinse the volumetric flasks (fill and dump) three times with deionized water.
- h. Rinse the volumetric flasks (fill and dump) three times with nanopure water.
- i. Invert the volumetric flasks and place them on a drying rack.

L. BASIC CALCULATIONS

ATP in sample
$$(g/mL) = (RU - RB) \times ATP$$
 in standard* (g/mL) (RIS - RU)

Solids in sample $(g/mL) = \underline{pan \ dry \ weight}$ (final-initial, grams) volume of sample (mL)

ATP per gram solids (g/g) = ATP in sampleSolids in sample

 $[\]pm 2.5 \times 10^{-8}$ g ATP/mL (Standard concentration currently prepared).

APPENDIX B

CHEMICAL COMPANIES CONTACTED

APPENDIX B

CHEMICAL COMPANIES CONTACTED

The following pages list the chemical companies that were contacted in order to establish what possibly biodegradable solvents are presently available. This list was compiled through personal conversations and the Thomas Register.

BIODEGRADABLE PROJECT COMPANIES CONTACTED LIST

3 D INC.

AAZ WESTERN FACTORY SUPPLY

ACME CLEANING EQUIPMENT

ADVANCE AEROSOL & CHEMICAL CO.

ALEXANDER CHEMICAL CO.

ALLIED SIGNAL INC

AMERICAN NIAGARA CORP.

AMREP INC.

ARCO CHEMICAL CO.

ASHLAND CHEMICAL CO.

ASHLAND OIL INC.

ATLANTIC RICHFIELD CO.

AURIC CORP.

BARON BLAKESLEE INC.

BARTLETT CHEMICALS INC.

BASF CORP. DEPT. 131-T

BEACON CHEMICAL CO. INC.

BEAM CHEMICAL CO. INC.

BEAVER ALKALI PRODUCTS

BETTER ENGINEERING MFG.

BIO-TEK INC.

BROWNING-FERRIS INDUSTRIES

BRULIN & CO.

BUILD-ALL CORP.

BURMAH TECHNICAL SERVICES

BY PASS OF AMERICA

CABOT CHEMICAL CORP.

CALIFORNIA CHEMICAL CO.

CALLA CHEMICAL OPERATION

CAPCO ENTERPRISES LTD.

CHEM POWER MFG.

CHEMDET INC.

CHEMICAL PRODUCTS, HOLT LLOYD CORP.

CHEMOK CORP. SUB. OF HI PORT INDUSTRIES

CHEMTRONICS INC.

CHEVRON

CHRYSLER CORP.

CIRCUIT CHEMISTRY CORP.

CLEMCO IND.

CRAIN CHEMICALS CO. INC.

CRC DIST/TWIN SPECIALISTS CORP.

CROWLEY CHEMICAL COMPANY

CRYSTAL REFINING CO.

DALCO INDUSTRIES LTD.

DARMEX

DELL MARKING SYSTEMS INC.

DETREX CORP.

DIAMOND SHAMROCK CORP.

DIVERSEY WYANDOTTE CORP.

DOBER CHEMICAL CORP.

DOW CHEMICAL CO

DREW INDUSTRIAL DIVISION

DU PONT DE NEMOURS

DUNBAR SALES & MFG.

EFCOR FAMILY OF COMPANIES

ELGENE CHEMICALS INC.

ENTHONE INC.

ESSCO CHEMICALS INC

ETHYL CORP.

EUREKA CHEMICAL CO.

EXXON CHEMICAL CO.

FINE ORGANICS CORP

FORMULA IV CORPORATION

FOSTER & COMPANY INC.

FREDERICK GUMM CHEMICAL CO.

FREMONT INDUSTRIES

GAF CORP.

GAMAGET EQUIPMENT, DIV SYBRON CHEMICALS INC.

GENERAL TEXAS CORP.

GETTY REFINING CO.

GIVANDEN CORP.

GOODRICH PROJUCT DIV.

GRANT CHEMICAL DIV., FERRO CORP

GRAYMILLS CORP.

GREAT VALLEY INDUSTRIES INC.

HACHET PETROLEUM CO.

HOLT LLOYD CORP.

HOMESTEAD INDUSTRIES INC.

HOOKER CHEMICAL, INDUSTRIAL CHEMICALS GROUP

HORIZON CHEMICALS INC.

HUKILL CHEMICAL CORP.

HUNTINGTON LABORATORIES

HY-KO ENVIRO-MAINTAINANCE PRODUCTS

HYDRITE CHEMICAL CO.

HYDROTEX INC.

HYLUBE INC.

INDUSTRIAL CHEM LABS

INDUSTRIAL CHEMICAL PRODUCTS

INDUSTRIAL SOAP CO.

INDUSTRIAL SOLVENTS CORP.

INSTA-CLEAN INC.

INTERNATIONAL PRODUCTS CORP.

JET-LUBE INC.

JOHNSON WAX/GEM STATE PAPER

JONES & LAUGHLIN STEEL CORP.

K&S ALL PURPOSE PRODUCTS

KANO LABORATORIES INC.

KELLOGG, E.H. AND CO. INC.

KENDALL/AMALIE DIV WITCO CORP.

KIESOW INTERNATIONAL CORP.

KLEAN STRIP, DIV W.M. BARR & CO. INC.

KLEER-FLO COMPANY

KLEM CHEMICAL CORP.

KUTOL PRODUCTS CO.

KWICK KLEEN INDUSTRIAL SOLVENTS

LAKE PRODUCTS CO. INC.

LEA MANUFACTURING CO.

LOCTITE CORP.

LONDON CHEMICAL CO.

LPS CHEMICAL PRODUCTS

LUFKIN CORP.

M-OIL-FREE CO.

MACDERMID CORP.

MADISON BIONICS

MAGIE BROS. OIL CO.

MAGNA IND. CO. LTD.

MAGNUS DIV OF ECONOOMICAL LABORATORY INC.

MAGNUS MERITEC INTERNATIONAL

MAGNUSON PRODUCTS

MAN-GILL CHEMICAL

MCGEAN-ROHCO INC.

MEQQEM

MICHIGAN INDUSTRIAL FINISHES CORP.

MILLER, HARRY, CORP.

MITCHELL-BRADFORD CHEMICAL CO.

MONTGOMERY CHEMICALS CO.

MORGAN CHEMICALS INC.

MULTI-CLEAN

NORTH COAST CHEMICAL CO

NORTON PETROLEUM CORP.

NOVOCOL CHEMICAL CO.

NUVITE CHEMICAL COMPOUNDS CORP.

OAKITE PRODUCTS INC.

OLIN CHEMICALS

ORANGE-SOL INC.

ORGANIC CHEMICAL DEV.

OVERDALE CORP.

PACE NATIONAL CORP.

PACIFIC CHEMICAL

PACLIN CHEMICAL CO

PANTHER CHEMICAL CO.

PARKER CHEMICAL CO.

PATCLIN CHEMICAL CO.

PAVCO INC.

PENETONE CORP.

PETROCON MARINE AND INDUSTRIAL CHEMICAL CORP.

PETROFIRM INC.

PHILLIPS MANUFACTURING CO.

PIERCE CHEMICAL CO.

PM PRODUCTS INC.

PPG INDUSTRIES INC., CHEMICAL GROUP

PRECISIONAIRE INC.

PROGRESS CHEMICAL INC.

PUREX CORP.

QUAKER OATS CHEMICALS

RADIATOR SPECIALTY CO.

RAWN CO. INC.

REICHHOLD CHEMICALS INC.

REM CHEMICAL CO.

RESEARCH CHEMICALS

RHONE POULENC INC.

ROBBISH INDUSTRIAL PROD.

ROCHESTER MIDLAND

ROLY INTERNATIONAL

ROMINDA INC.

ROTO FINISH

RUST ELIMINATOR CO.

S.C. JOHNSON & SON

SECO CHEMICALS INC.

SEMCO DIV, PRODUCTS RESEARCH & CHEMICAL CORP.

SENTINEL SOAPA AND CHEMICAL CO.

SHELL CHEMICAL CO.

SPECTRON INC.

STANDARD OIL CO.

STARKEY CHEMICAL PROCESS CO.

STEPAN CO.

STERLING-CLARK-LURTON CORP.

SUN REFINING & MARKETING CO.

SURFACE DYNAMICS USA INC.

SUTTON CORP.

SWI INTERNATIONAL INC.

TELSTAR INDUSTRIES, INC.

TOWER CHEMICAL CORP.

TRUESDALE CO.

TURCO PRODUCTS

TWIN SPECIALTIES CORP.

U.S. POLYCHEMICAL CORP.

U.S.I. CHEMICALS, DIV OF NATIONAL DISTILLERS AND C

UNION CHEMICALS DIV., PETRO CHEMICAL GROUP

UNIQUE INDUSTRIES INC.

UNITED LABORATORIES INC.

UNOCAL CORP.

VALESKA SOVENTS INC.

VALVE LINE LABORATORIES

VAN STRAATEN CHEMICAL CO.

VIRGINIA CHEMICALS INC.

VIRGINIA KMT

VISTA CHEMICAL CO.

WARNER-GRAHAM CO.

WASTE REASEARCH & RECLAMATION CO.

WESTERN CHEMICAL CO.

WITCO CORP

WORLD LABORATORIES

** Z

ZEP MFG. CO.

ZIEBART PRODUCTS

APPENDIX C

COMPOUNDS CHOSEN FOR EVALUATION

APPENDIX C

COMPOUNDS CHOSEN FOR EVALUATION

These pages contain the compounds with thorough discussions with manufacturers who were selected for testing.

BIODEGRADABLE SOLVENTS PRODUCTS RECIEVED

** 3 D INC.

3D SUPREME

747 AIRCRAFT CLEANER

BRITE BOY

CITRIGOLD

RUST ERADICATOR

SIEGE

** AMERICAN NIAGARA CORP. ACCUSOL S/T-20

** BARTLETT CHEMICAL INC.
DOLPHIN 281
DOLPHIN TPS CODE 219
DOLPHIN WSD CCDE 207
TOBY CODE 230

** BIO-TEK INC.

122 QUIK

126 SONI-CLEAN

134 HI-SOLV

710 dry clean

SAFTEY SOLVENT DEGREASER

** BRULIN
711 SC
815 QR
AQUA SAFE
CL-500
FORMULA 512M
NATURE-SOL 100

- ** BUILD ALL BAC #137
- ** CABOT CHEMICAL CORP. X-166
- ** CALLA CHEMICAL CORP CALLA 301 CALLA 301-A CALLA 301-A-LEMON CALLA 626B CALLA 800
- ** CHEMIQUE INC BAR-2-NU ION-417X ION-420/LC KRC-7
- ** CIRCUIT CHEMISTRY CORPORA NCN-CU A,B
- ** CROWLEY CHEMICAL COMPANY
 AROMATIC SOLVENT #58
 METHYL NAPHTHALENE #5
- ** DIVERSEY WYANDOTTE METALS
 ALDET
 DIVERCLEAN LTS
 DIVERSEY WYADOTTE II
 NUVAT
 NUVAT LT
 NUVAT NP
 PORENAC

** DOBER CHEMICAL CORP.

4190

8679

CD-44

CD-44HD

** DREW INDUSTRIAL DIVISION DREW OIL AND GREASE REM.

** ELGENE CHEMICALS INC.

#22 SKID00

A-CD

ECONOMISER CF

FABULENE

SAFETY SOLVENT #10

** EXXON CHEMICALS

AROMATIC 150

ARCMATIC 200

EXSOL D 80

EXXAL 13 TRIDECYL ALCOHOL

EXXAL 16 - ISOCETYL ALCOHO

EXXAL 20

EXXAL L1315

EXXATE 1000

EXXATE 1300

EXXATE 600

EXXATE 700

EXXATE 800

EXXATE 900

EXXSOL D110

NORPAR 13

NORPAR 15

WS 2443 SOLVENT

WS 2444 SOLVENT

** FINE ORGANICS CORP F.O. 2074

** FORMULA IV CORPORATION MAGNA IV C-1000

** FREDERICK GUMM CHEM.

CLEPO 136-R

CLEPO 136-R

CLEPO 204

CLEPO 426-A

CLEPO 644-L

CLEPO 681-L

SONIC SOAK

** GRAYMILLS CORP.

AGITENE

AQUATENE 330

AQUATENE 571

AQUATENE 581

** HOLT LLOYD CORP.
CHEMPRO APC

CPS HEAVY DUTY CLEANER

** HOMESTEAD INDUSTRIES INC.

#49

#49-S

#65

AP

HDL

** HUNTINGTON

J8-10P

LHTS

ONLINE CE SD

SOLVENT EMULTION DEGREASE THUNDER BOLT

- ** HYDRITE CHEMICAL CO. HYDRI-CLEAN NPX
- ** HYLUBE INC.
 ALKAKLEEN 658
 HYKLEEN 300
 HYKLEEN 312
- ** INTERNATIONAL PRODUCTS CO MICRO
- ** JOHNSON WAX/GEM STATE PAP BIG BARE J-SHOP 500 J-SHOP 600
- ** KIESOW INTERNATIONAL CORP EKASIT D-103 EKASIT E-231 EKASIT S-261
- ** KLEER-FLO COMPANY
 DEGREASOL 99R
 HI-T DEGREASER
- ** LAKE PRODUCTS CO. INC. LAKE-97
- ** LEA MANUFACTURING CO. CLEANOL
- ** M-OIL-FREE CO. CITRIC

GS-A-67 M-OIL-FREE #1000 ULTRA ULTRA 70 ULTRA 90

- ** MADISON BIONICS CHEMERSE
- ** MAGNUSON PRODUCTS
 PERMAG #404
 ** MAN-GILL CHEMICAL
 MAGNUSOL 728
- ** MEQQEM MEQQEM-CLEAN 8512 MEQQEM-CLEAN 8516
- ** MIRACHEM 100
- ** MITCHELL-BRADFORD, INTERN
 MI-CLEAN 100
 MI-CLEAN 14
 MI-CLEAN 31
 MI-CLEAN 59
- ** NORTH COAST CHEMICAL CO CARBON REMOVER 730
- ** OAKITE PRODUCTS INC.
 OAKITE 162
 OAKITE 2327
 OAKITE 24
 OAKITE ANOPREP

OAKITE DYNADET
OAKITE HD 126

** ORANGE-SOL INCORPERATED DE-SOLV-IT

** PACIFIC CHEMICAL

FIST

MASTER MHW

PACE S-L

RIDDALL

** PANTHER CHEMICAL CO.

759

AS-33

CR-138

CR-140

RR 50

** PARKER CHEMICAL PARCO CLEANER 2033 PARCO CLEANER 2053

** PATCLIN CHEMICAL CO.

#309

#348

#380

#490

330 BEC

- ** PENETONE CITRI KLEEN
- ** PETROFIRM INC.
 BIOACT INDUSTRIAL DG1

** PROGRESS CHEMICAL INC.

#611

#65

AC-1 L-365

- ** ROCHESTER MIDLAND SE377C
- ** SUTTON CORP.
 TOPSALL
- ** TELSTAR INDUSTRIES
 TELE-SOLV
 TOWER 270
- ** TITAN CHEMICAL OIL-FLO
- ** TRI TON HEMO-SOL
- ** TWIN SPECIALTIES CORP.
 CLEANER 54-TWIN INDUSTRIA
 TWIN CITRON CLEANER 100
- ** U.S. POLYCHEMICAL CORP. ST-21 POLY SPRAY JET
- ** UNITED LABORATORIES
 UNITED 392
 UNITED 395
- ** VAN STRAATEN CHEM CO. 21-271-A

3625 VANSTAATEN CUTTER

- ** VIRGINIA KMT VIRGINIA-10
- ** ZEP MANUFACTURING CO.
 BIG ORANGE
 ZEP 940
 ZEPRIDE

APPENDIX D

RECOMMENDED CONDITIONS

These pages contain the conditions at which, initially, each compound was tested. These conditions were received directly from the manufacturer

3 D INC.

3D SUPREME

INGREDIENT --- DIPROPYLENE GLYCOL, MONOMETHYL ETHER

APPLICATION -- GREASE, OIL, CARBON, WAX

METALS ----- STEEL, Cr, Cd, BRONZE, IRON, Ni, Cu, SS, Pb, BRASS, Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1-3 | 140 |
| 1-3 | 160 |
| 1-3 | 180 |
| | |

3 D INC.

747 AIRCRAFT CLEANER

INGREDIENT --- DETERGENT

APPLICATION -- SOILS

METALS ----- Al, Cd, PLATE

| SUGGESTED | CONCENTRATIONS | TEMPERATURE | °F |
|-----------|----------------|-------------|----|
| | | | |

3 D INC.

BRITE BOY

INGREDIENT --- POTASSIUM HYDROXIDE
APPLICATION -- GREASE, CIL, WAX, CARBON
METALS ----- AL

| SUGGESTED | CONCENTRATIONS | TEMPERATURE | e °F |
|-----------|----------------|-------------|------|
| | | | - |

3 D INC.

CITRIGOLD

INGREDIENT --- ORANGE OIL BASE

APPLICATION -- GREASE, OIL, CARBONIZED OIL

METALS ---- STEEL, Cr, Cd, BRONZE, Fe, Ni, Cu, SS, BRASS, Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:1 | 140 |
| 1:1 | 160 |
| 1:1 | 180 |
| CONCENTRATE | 140 |
| CONCENTRATE | 160 |
| CONCENTRATE | 180 |
| | |

3 D INC.

RUST ERADICATOR

INGREDIENT ---

APPLICATION -- RUST

METALS ----- STEEL, SS, Fe

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1-1 | 75 |
| 1-1 | 140 |
| 1-1 | 200 |
| | |

3 D INC.

SIEGE

INGREDIENT --- DIPROPYLENE GLYCOL MONOMETHYL ETHER

APPLICATION -- MULTIPURPOSE

METALS ----- STEEL, Cr, Cd, BRONZE, Fe, Ni, Cu, SS, Pb, BRASS

| SUGGESTED CONCENTRATION | NS TEMPERATURE °F |
|-------------------------|-------------------|
| 1:4 | 160 |

BARTLETT CHEMICAL INC. DOLPHIN 281 INGREDIENT --- PROPYLENE GLYCOL METHYL ETHER APPLICATION -- HEAVY CLEANING METALS ----- NONE SPECIFIED

| SUGGESTED CONCENTRATIONS | TEMPERATURE *1 |
|--------------------------|----------------|
| 1:1 | AMBIENT |
| 1:4 | AMBIENT |

BARTLETT CHEMICAL INC. DOLPHIN TPS CODE 219

INGREDIENT --- ACIDS, STRONG ALKALINES

APPLICATION -- OIL, DEGREASEING

METALS ----- ALL METALS

| | SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|---|--------------------------|--------------------|
| _ | 1:10 1:20 | AMBIENT AMBIENT |
| | | |

. BARTLETT CHEMICAL INC. DOLPHIN WSD CODE 207

INGREDIENT --- PROPYLENE GLYCOL METHYL ETHER APPLICATION -- SOIL, GREASE, OIL

METALS ----- ALL

| | SUGGESTED | CONCENTRATIONS | TE | MPERATURE | °F |
|---|-----------|----------------|----|-----------|----|
| _ | 4 | OZ/GAL | | 160 | |
| | | | | | |

BARTLETT CHEMICAL INC. TOBY CODE 230 INGREDIENT --- PROPYLENE GLYCOL METHYL ETHER APPLICATION -- HEAVY CLEANING METALS ----- ALL TEMPERATURE °F SUGGESTED CONCENTRATIONS AMBIENT 1:3 1:10 AMBIENT 122 QUIK BIO-TEK INC. INGREDIENT --- 2-BUTOXYETHANOL APPLICATION -- OIL, GREASE METALS ---- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F BIO-TEK INC. 126 SONI-CLEAN INGREDIENT --- 2-BUTOXYETHANOL, ANIONIC SURFACTANTS APPLICATION -- ALL PURPOSE METALS ----- ALL ULTRASONIC CLEANER SUGGESTED CONCENTRATIONS TEMPERATURE °F BIO-TEK INC. 134 HI-SOLV

INGREDIENT --- ALKYL ACETATE ESTERS

APPLICATION -- DEGREASER

METALS ----- ALL

SUGGESTED CONCENTRATIONS

TEMPERATURE *F

CONCENTRATE

AMBIENT

BIO-TEK INC.

SAFTEY SOLVENT DEGREASER

INGREDIENT --- ALKYL ACETATE ESTERS

APPLICATION -- DEGREASER

METALS -----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBIENT

BLUE GOLD

BLUE GOLD

INGREDIENT ---

APPLICATION --

METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

711 SC

BRULIN

INGREDIENT --- ETHANOLAMINE, 2-AMINOETHANOL, MONOETHANOLAMINE APPLICATION -- OIL, GREASE METALS ----- ALL

NOT AL

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 1:3 | 130 |
| 1:3 | 150 |

BRULIN

815 QR

INGREDIENT --- ETHANOLAMINE, 2-AMINOETHANOL MONOETHANOLAMINE APPLICATION -- OIL, GREASE

METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:20 | 160 |
| 1:20 | 180 |
| 1:20 | 200 |
| 1:10 | 160 |
| 1:10 | 180 |
| 1:10 | 200 |

BRULIN

AQUA SAFE

INGREDIENT --- DIPROPYLENE GLYCOL METHYL ETHER 2 PROPANOL, 1 METHOXY; YENE GYLCOL METHYL ETHER

APPLICATION -- GREASE OIL

METALS ----- STEEL, Al, Cu, BRASS

| SUGGESTED CONCENTRATIONS | T TMPERATURE °F |
|--------------------------|-----------------|
| 1:5 | 160 |
| 1:10 | 160 |

BRULIN CL-500

INGREDIENT --- SODIUM HYDROXIDE CAUSTIC SODA

APPLICATION -- CARBON REMOVER METALS ----- NONE SPECIFIED

| SUGGESTED CONCENTRATIONS | TEMPERATURE *F |
|--------------------------|----------------|
| 4 OZ/GAL | 180 |
| 4 OZ/GAL | 210 |
| 6 OZ/GAL | 180 |
| 6 OZ/GAL | 210 |
| 8 OZ/GAL | 180 |
| 8 OZ/GAL | 210 |

BRULIN

FORMULA 512M

INGREDIENT --- NAPTHALENE, 2-BUTOXYETHANOL, GLYCOL MONOBUTYL ETHER

APPLICATION -- OIL, GREASE

METALS ----- NONE SPECIFIED

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:4 | 150 |
| 1:10 | 150 |

BRULIN

NATURE-SOL 100

INGREDIENT --- DIPROPYLENE GLYCOL METHLY ETHER

APPLICATION -- GREASE, OIL, WAX

METALS ----- NONE SPECIFIC

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|--------------------|
| CONCENTRATE 1-3 | AMBIENT AMBIENT |

BAC #137

BUILD ALL

INGREDIENT --- POTASIUM HYDROXIDE, SODIUM NITRATE

APPLICATION -- OILS, SOILS

METALS ----- ALL

MAY STAIN Mg

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4% | 90 |
| 4% | 120 |
| 48 | 150 |
| 7% | 90 |
| 7% | 120 |
| 7% | 150 |
| 10% | 90 |
| 10% | 120 |
| 10% | 150 |
| | |

CABOT CHEMICAL CORP. X-166

INGREDIENT --- PROPRIETARY

APPLICATION -- OIL, GREASE

METALS ---- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| | • |
| 1:50 | AMBIENT |
| 1:20 | AMBIENT |
| | |

CALLA CHEMICAL CORP CALLA 301

INGREDIENT --- BUTOXYETHANOL, POTASSIUM HYDROXIDE

APPLICATION -- GREASE, OIL, CARBON

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:1 | 100 |
| 1:4 | 140 |

CALLA CHEMICAL CORP CALLA 301-A

INGREDIENT --- BUTOXYETHANOL, POTASSIUM HYDROXIDE

APPLICATION -- GREASE, OIL, CARBON

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:4 | 120 100 |

CALLA CHEMICAL CORP CALLA 301-A-LEMON

INGREDIENT --- BUTOXYETHANOL, POTASSIUM HYDROXIDE

APPLICATION -- GREASE, OIL, CARBON, WAX

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:4 | 120 |
| 1:1 | 100 |
| | |

CALLA CHEMICAL CORP CALLA 800

INGREDIENT --- POTASIUM HYDROXIDE

APPLICATION -- OIL GREASE EXHAUST STAINS

METALS ----- NONE SPECIFIED

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | 120 |
| 1:3 | 120 |

CONTROL

CONTROL

INGREDIENT ---APPLICATION --METALS -----TEMPERATURE °F SUGGESTED CONCENTRATIONS NO SUGGESTED CONCENTRATION CROWLEY CHEMICAL COMPANY AROMATIC SOLVENT #58 INGREDIENT ---APPLICATION --METALS -----TEMPERATURE 'F SUGGESTED CONCENTRATIONS CROWLEY CHEMICAL COMPANY METHYL NAPHTHALENE #5 INGREDIENT --- NAPHTHALENE APPLICATION -- OIL, GREASE METALS ----- ALL

NOT BIODEGRADABLE

SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT

DOBER CHEMICAL CORP.

4190

INGREDIENT --- 2-BUTOXYETHANOL, NaOH, SODIUM META SILICATE APPLICATION -- OIL, GREASE METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:20 | AMBIENT |
| 1:60 | AMBIENT |
| 1:100 | AMBIENT |

DOBER CHEMICAL CORP. 8679

INGREDIENT --- SODIUM HYDROXIDE APPLICATION -- OIL, GREASE

METALS ----- FERROUS METALS, COPPER

NOT FOR Al, Zn

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4 OZ/GAL | 120 |
| 4 OZ/GAL | 160 |
| 4 OZ/GAL | 200 |
| 10 OZ/GAL | 120 |
| 10 OZ/GAL | 160 |
| 10 OZ/GAL | 200 |
| 16 OZ/GAL | 120 |
| 16 OZ/GAL | 160 |
| 16 OZ/GAL | 200 |
| 16 02/GAL | 200 |

DREW INDUSTRIAL DIVISION DREW OIL AND GREASE REM.

INGREDIENT --- PETROLEUM DISTALLATE ETHYLENE OXIDE, PHOSPHATE ESTER APPLICATION -- OIL, GREASE METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|-------------------------------------|--------------------|
| CONCENTRATE CUT 4 X W/PETRO SOLVENT | AMBIENT AMBIENT |
| COI 4 N W/ILINO SOLIVENI | ANDIENI |

ELGENE CHEMICALS INC. #22 SKIDOO

INGREDIENT --- ALKALI DETERGENT APPLICATION -- OIL, GREASE, WAX, PAINT METALS ----- ALL ETCHES Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:5 | 120 |
| 1:5 | 160 |
| 1:5 | 180 |
| | |

ELGENE CHEMICALS INC. A-CD

INGREDIENT --- PHOSPHORIC ACID APPLICATION -- OIL, GREASE METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:10 BRASS COPPER | 120 |
| 1:10 BRASS COPPER | 180 |
| 1:5 STEEL, AL | 120 |
| 1:5 STEEL, AL | 180 |

ELGENE CHEMICALS INC. ECONOMISER CF

INGREDIENT --- SODIUM METASILICATE TERPENTAYHDRATE, ETHYLENE GLYCOL BUTTHER

APPLICATION -- GREASE, OIL, WAX

METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1 OZ/GAL | AMBIENT |
| 6 OZ/GAL | AMBIENT |
| 12 OZ/GAL | AMBIENT |
| CONENTRATE | AMBIENT |

ELGENE CHEMICALS INC. FABULENE INGREDIENT --- SODIUM METASILICATE SODIUM HYDROXIDE APPLICATION -- GREASE, OIL, CARBON, WAX METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F 1:2 160 1:6 160 ELGENE CHEMICALS INC. SAFETY SOLVENT #10 INGREDIENT ---APPLICATION -- GREASE, OIL METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F NO SUGGESTED CONCENTRATION EXXON CHEMICALS AROMATIC 150 INGREDIENT --- NAPTHA APPLICATION --METALS -----SUGGESTED CONCENTRATIONS TEMPERATURE °F

- :

INGREDIENT --- NAPTHA APPLICATION --METALS -----

| | SUGGESTED CO | DNCENTRATIONS | TEM | PERATURE | °F |
|---|-------------------|------------------|--------------|-----------|-----|
| *************************************** | | | | | |
| | | | | | |
| EXXON CHE | MICALS | EXSOL D 80 | | | |
| APPLIC | IENT C11 ATION | L-C13 PARAFFINS, | NAPTHENIC 1 | HYDROCARB | ONS |
| | SUGGESTED CO | ONCENTRATIONS | TEM | PERATURE | °F |
| | | | | | |
| | | | | | |
| EXXON CHE | MICALS | EXXAL 13 TR | IDECYL ALCO | HOL | |
| APPLIC | IENT TRI ATION | IDECANOL | | | |
| | SUGGESTED CO | ONCENTRATIONS | TEM | PERATURE | °F |
| | | | | | |
| ******* | | | | | |
| EXXON CHE | MICALS | EXXAL 16 -I | SOCETYL ALCO | ОНО | |
| APPLIC | IENT ISO ATION | OCETYL ALCOHOL | | | |
| | SUGGESTED CO | DNCENTRATIONS | TEM | PERATURE | °F |
| | | | | | |

EXXON CHEMICALS EXXAL 20

INGREDIENT --- ISOARACHIDYL ALCOHOL APPLICATION --METALS -----SUGGESTED CONCENTRATIONS TEMPERATURE °F EXXON CHEMICALS EXXAL L1315 INGREDIENT --- OXO ALCOHOL APPLICATION --METALS -----SUGGESTED CONCENTRATIONS TEMPERATURE °F EXXON CHEMICALS EXXATE 1000 INGREDIENT --- C10H210COCH2 APPLICATION -- REPLACE CHLORINATED HYDROCARBONS METALS ---- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT EXXON CHEMICALS EXXATE 1300 INGREDIENT --- C13H27OCOCH3 APPLICATION -- REPLACE CHLORINATED HYDROCARBONS METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT

EXXON CHEMICALS

EXXATE 600

INGREDIENT --- C6H13OCOCH2 APPLICATION -- REPLACE CHLORINATED HYDROCARBONS METALS ----- ALL TEMPERATURE °F SUGGESTED CONCENTRATIONS CONCENTRATE AMBIENT EXXATE 700 EXXON CHEMICALS INGREDIENT --- C7H15OCOCH2 APPLICATION -- REPLACE CHLORINATED HYROCARBONS METALS ---- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT EXXON CHEMICALS EXXATE 800 INGREDIENT --- C8H17OCOCH2 APPLICATION -- REPLACE CHLORINATED HYDROCARBONS METALS -----SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT EXXON CHEMICALS EXXATE 900 INGREDIENT --- C9H19OCOCH2 APPLICATION -- REPLACE CHLORINATED HYDROCARBONS METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F

AMBIENT

CONCENTRATE

EXXON CHEMICALS

. :

EXXSOL D110

| INGREDIENT PETROLEUM HYDROCARBON APPLICATION METALS | |
|--|----------------|
| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
| | |
| EXXON CHEMICALS NORPAR 13 | |
| INGREDIENT C13-C14 PARAFFINS APPLICATION METALS | |
| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
| | |
| EXXON CHEMICALS NORPAR 15 INGREDIENT C14-C17 PARAFFINS APPLICATION METALS | |
| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
| | |
| EXXON CHEMICALS WS 2443 SOLVENT | |
| INGREDIENT PETROLEUM DISTILLATE APPLICATION METALS | |
| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
| | |

EXXON CHEMICALS WS 2444 SOLVENT

INGREDIENT --- HYDROCARBON DISTILLATE APPLICATION --

METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

FINE ORGANICS CORP COMPOUND CLEANING LIQUID

INGREDIENT ---

APPLICATION --

METALS ----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

FINE ORGANICS CORP SOLVENT EMULSION

INGREDIENT ---

APPLICATION --

METALS ----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

FORMULA IV CORPORATION MAGNA IV C-1000

INGREDIENT --- PROPRIETARY

APPLICATION -- OIL, GREASE EMULSIFIER

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE *F |
|--------------------------|----------------|
| 1:15 | AMBIENT |
| 1:10 | AMBIENT |

FREDERICK GUMM CHEM. CLEPO 136-R

INGREDIENT --- SODIUM SILICATE, TERASODIUM, PROPHOSPHATE, SODIUM DODECY **ENE SULFONATE**

APPLICATION -- OIL, GREASE

METALS ----- Al, BRASS, Cu, Ni, Ni-Ag, SS, STEEL, TIN, Zn

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1 OZ/GAL Al | 170 |
| 6 OZ/GAL BRASS | 180 |
| 8 OZ/GAL Cu | 200 |
| 8 OZ/GAL Ni | 200 |
| 6 OZ/GAL Ni-Ag | 210 |

FREDERICK GUMM CHEM. CLEPO 136-R

INGREDIENT ---

APPLICATION --

METALS -----

***** CONTINUATION OF RECORD *****

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 8 OZ/GAL SS | 210 |
| 8 OZ/GAL STEEL | 210 |
| 4 OZ/GAL TIN | 200 |
| 4 OZ/GAL ZINK | 180 |

FREDERICK GUMM CHEM. CLEPO 204

INGREDIENT --- ALKYL AMINE APPLICATION -- GREASE, OIL METALS ----- STEEL, Cu, BRASS

SUGGESTED CONCENTRATIONS

TEMPERATURE 'F

FREDERICK GUMM CHEM. CLEPO 644-L

INGREDIENT --- Z-BUTOXY ETHANOL, SODIUM DODECYLBENZENE SULFONATE APPLICATION -- GREASE, OIL METALS ----- STEEL, Cu, BRASS ETCHES Al, MILD ATTACK OF ZINC

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4% STEEL, Cu | 150 |
| 4% STEEL, Cu | 180 |
| 6% STEEL, Cu | 150 |
| 6% STEEL, Cu | 180 |
| 3% BRASS | 150 |
| 3% BRASS | 180 |
| 5% BRASS | . 150 |
| 5% BRASS | 180 |
| | |

FREDERICK GUMM CHEM. SONIC SOAK

INGREDIENT --- MONO ETHANOL AMINE

APPLICATION -- BUFFING & POLISHING RESIDUES OIL

METALS ----- STEEL, Zn, BRASS, Pb, Al

| SUGGESTED CO | NCENTRATIONS | TEMPERATURE 'F | |
|--------------|-------------------|----------------|--|
| 2% | STEEL | 140 | |
| 2% | STEEL | 170 | |
| 2% | STEEL | 190 | |
| 3% | STEEL | 140 | |
| 3% | STEEL | 170 | |
| 3% | STEEL | 190 | |
| 0.5% | BRASS, Pb, Al | 140 | |
| 0.5% | BRASS, Pb, Al | 170 | |
| 0.5% | BRASS, Pb, Al | 190 | |
| 2% | Zn, BRASS, Pb, Al | 140 | |
| 2% | Zn, BRASS, Pb, Al | 170 | |
| 28 | Zn, BRASS, Pb, Al | 190 | |

GOLDENWEST

WBS

INGREDIENT ---APPLICATION --METALS ----

| SUCCESTED | CONCENTRATIONS |
|-----------|----------------|

· TEMPERATURE °F

NO SUGGESTED CONCENTRATION

GRAYMILLS CORP.

AQUATENE 330

INGREDIENT --- DOWANOL DPM, ALKALINE DETERGENT

APPLICATION -- OIL, GREASE, WAX

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F | |
|--------------------------|----------------|--|
| 1:4 | 150 | |
| 1:4 | 180 | |
| 1:9 | 150 | |
| 1:9 | 180 | |

GRAYMILLS CORP. AQUATENE 571

INGREDIENT --- SODIUM METASILICATE APPLICATION -- VARNISH, CARBON, OIL, WAX METALS ----- Al NON FERROUS METALS CAUTION WITH PLATED METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 2 OZ/GAL | 180 |
| 5 OZ/GAL | 180 |
| 8 OZ/GAL | 180 |

GRAYMILLS CORP.

AQUATENE 581

INGREDIENT --- ALKALINE APPLICATION -- CARBON, OIL, WAX, VARNISH METALS ----- ALLOY STEELS MAY REMOVE PLATING

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 12 OZ/GAL | 200 |
| 20 OZ/GAL | 200 |

HOLT LLOYD CORP.

CHEMPRO APC

INGREDIENT --- GLYCOL ETHER, PHOSPHATES, SILICATES APPLICATION -- GREASE, OIL, WAX, SOIL METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|--------------------|
| 1:6 | AMBIENT AMBIENT |
| 1.2 | AMBIENI |

HOMESTEAD INDUSTRIES INC. #49

INGREDIENT --- CAUSTIC SODA APPLICATION -- OIL, GREASE METALS ----- ALL

NOT Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 19 OZ/GAL | AMBIENT |

HOMESTEAD INDUSTRIES INC.#49-S

INGREDIENT --- CAUSTIC SODA APPLICATION -- OIL, GREASE, PAINT METALS ----- ALL NOT Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 19 OZ/GAL | AMBIENT |

HOMESTEAD INDUSTRIES INC. #65

INGREDIENT --- KOH
APPLICATION -- OIL, GREASE
METALS ----NOT Al, Mg SOFT METALS, PRESSURE WASHER

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:250 | AMBIENT |

HOMESTEAD INDUSTRIES INC.AP

INGREDIENT --APPLICATION -- MINERAL OIL, GREASE
METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 12 OZ/GAL | AMBIENT |

HOMESTEAD INDUSTRIES INC. HDL

INGREDIENT --- CAUSTIC POTASH, KOH APPLICATION -- HEAVY DUTY CLEANING METALS -----NOT A1, PRESSURE WASHER

| 1:250 AMBIENT | | SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|---------------|---|--------------------------|----------------|
| | _ | 1:250 | AMBIENT |

HUNTINGTON

J8-10P

INGREDIENT --- ALKALINE
APPLICATION -- GREASE OIL, WAX
METALS ----- ALL

SUGGESTED CONCENTRATIONS TEMPERATURE °F

HUNTINGTON

LHTS

INGREDIENT --APPLICATION -- OIL, GREASE, PAINT
METALS ---- FE, STEEL, BRASS, Pb, BRONZE, CU, Ni, Cd, Mg, SS, Cr
LIQUID HOT TANK STRIPPER

| SUGGESTED | CONCENTRATIONS | TEMPERATURE °F |
|-----------|----------------|----------------|
| 1 | OZ/GAL | 160 |
| 3 | OZ/GAL | 160 |
| 6 | OZ/GAL | 160 |

HUNTINGTON

ONLINE CE SD

INGREDIENT ---

APPLICATION -- OIL, GREASE, CARBON

METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |

HUNTINGTON

SOLVENT EMULTION DEGREASE

INGREDIENT --APPLICATION -- OIL, GREASE CARBON
METALS ----- ALL
PRODUCT, ENDS IN SED

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|----------------------------|----------------|
| NO SUGGESTED CONCENTRATION | |

HUNTINGTON

THUNDER BOLT

INGREDIENT --APPLICATION -- GREASE, OIL
METALS ----- ALL
NOT Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|--------------------|
| 1:3 1:2 | AMBIENT AMBIENT |

HYDRITE CHEMICAL CO. HYDRI-CLEAN NPX

INGREDIENT --- TETRA POTASIUM PYROPHOSPHATE, POTASIUM HYDROXIDE DODECY ZENE SULFONIC ACID, PROPYLENE GLYCOL

APPLICATION -- OIL, GREASE, SOIL

METALS ----- STEEL, SS, Fe

NOT FOR Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:1 | 100 |
| 1:1 | 130 |
| 1:4 | 100 |
| 1:4 | 130 |
| | |

HYLUBE INC.

ALKAKLEEN 658

INGREDIENT ---

APPLICATION -- GREASE, OIL, RUST, PAINT

METALS ----- STEEL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F | |
|------------------------------|----------------|--|
| 1:10 | 190 | |

HYLUBE INC.

HYKLEEN 300

INGREDIENT --- ISOPROPANOL 5% APPLICATION -- OIL, GREASE, WAX METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE *F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |
| 1:4 | AMBIENT |

HYLUBE INC. HYKLEEN 312

INGREDIENT ---

APPLICATION -- GREASE

METALS ----- Al, NONFERROUS METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|----------------------------|----------------|
| NO SUGGESTED CONCENTRATION | |

INTERNATIONAL PRODUCTS COMICRO

INGREDIENT --- SODIUM AMMONIUM, TRIETHANOLAMMOUNIUM, ETHYELEDIAMINE TE TATE

APPLICATION -- OIL, GREASE, WAX METALS ----- ALL

MAY ETCH Zn, Al

| SUGGESTED | CONCENTRATIONS | TEMPERATURE °F |
|-----------|----------------|----------------|
| 2 | OZ/GAL | 200 |

JOHNSON WAX/GEM STATE PAPBIG BARE

INGREDIENT --- ALKALI METASILICATE & CARBONATES, SURFACTANTS
APPLICATION -- DIRT, GREASE, OIL
METALS ---- Fe, SS, CERAMIC, Cr, BRONZE, Zn, Cu, BRASS, Sn, Cd, Fb,

| SUGGESTED | CONCENTRATIONS | } | TEMPERATURE | °F |
|-----------|----------------|---|-------------|----|
| 1 | :15 | | 180 | |

JOHNSON WAX/GEM STATE PAPJ-SHOP 500

INGREDIENT --- POTASSIUM CARBONATE, SODIUM METASILICATE, NONYLPHENOL POL LENE GLYCOL ETHER

APPLICATION -- WIDE VARIETY O OILS &GREASE

METALS ---- Fe, SS, CERAMIC, Cr, Al, BRONZE, Zn, Cu, BRASS, TN, Cd, Pb

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1:4 | 100 |

JOHNSON WAX/GEM STATE PAPJ-SHOP 600

INGREDIENT --- ETHYLENE GLYCOL MONOBUTYL ETHER, NONYLPHENOL POLYETHYLEN COL ETHER

APPLICATION -- DEGREASEING

METALS ----- Fe, SS, CERAMIC, PLASTIC, CHROME, A1, BRONZE, Zn, Cu, BRASS, Sn, C

| SUGGESTED CONCENTRA | ATIONS TEMPERATURE | °F |
|---------------------|--------------------|----|
| 1:10 | 100 | |

KIESOW INTERNATIONAL CORPEKASIT D-103

INGREDIENT --- CAUSTIC SODE APPLICATION -- DESCALING METALS ----- Fe, STEEL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 7 OZ/GAL | 140 |
| 7 OZ/GAL | 160 |
| 7 OZ/GAL | 212 |
| 15 OZ/GAL | 140 |
| 15 OZ/GAL | 160 |
| 15 OZ/GAL | 212 |
| 30 OZ/GAL | 140 |
| 30 OZ/GAL | 160 |
| 30 OZ/GAL | 212 |

KIESOW INTERNATIONAL CORPEKASIT E-231

INGREDIENT --- CAUSTIC SODA, P205

APPLICATION -- ELECTROCLEANER

METALS ----- NON-FERROUS METALS, STEEL

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 5 OZ/GAL | 95 |
| 5 OZ/GAL | 140 |
| 8 OZ/GAL | 95 |
| 8 OZ/GAL | 140 |

KIESOW INTERNATIONAL CORPEKASIT S-261

INGREDIENT --- CAUSTIC SODA, P205 APPLICATION -- MULTIPURPOSE METALS ----- BRASS, Cu

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 6 OZ/GAL | 160 |
| 6 OZ/GAL | 185 |
| 8 OZ/GAL | 160 |
| 8 OZ/GAL | 185 |

KLEER-FLO COMPANY DEGREASOL 99R

INGREDIENT --- ALIPHATIC HYDROCARBON MIXTURE APPLICATION -- GREASE, OIL

METALS -----

TEMPERATURE "F SUGGESTED CONCENTRATIONS

KLEER-FLO COMPANY DG-5

INGREDIENT ---APPLICATION --METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE 'F

NO SUGGESTED CONCENTRATION

KLEER-FLO COMPANY HI-T DEGREASER

INGREDIENT --- ALIPHATIC HYDROCARBON MIXTURE

APPLICATION -- GREASE, OIL

METALS ----- ALL

SUGGESTED CONCENTRATIONS TEMPERATURE 'F

LAKE PRODUCTS CO. INC. LAKE-97

INGREDIENT --- SURFACTANTS IN WATER APPLICATION -- GREASE, OIL, CARBON

METALS ----- ALL

TEMPERATURE °F

1:7

AMBIENT

LEA MANUFACTURING CO. CLEANOL

INGREDIENT --- DIETHANOLAMINE

APPLICATION -- OIL, GREASE

METALS ----- Al, BRASS, Cu, STEEL, Zn

| SUGGESTED | CONCENTRATIONS | TEMPERATURE | °F |
|-----------|------------------|-------------|----|
| | OZ/GAL OZ/GAL | 180 200 | |
| | | | |

M-OIL-FREE CO. CITRIC

INGREDIENT --- ISOPROPANOL

APPLICATION --METALS -----

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |

M-OIL-FREE CO. GS-A-67

INGREDIENT --- SOIDUM HYDROXIDE, ISOPROPANOL APPLICATION --

METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBIENT

M-OIL-FREE CO. M-OIL-FREE #1000

INGREDIENT --- ISOPROPONAL

APPLICATION -- GREASE

METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBIENT

M-OIL-FREE CO.

ULTRA

INGREDIENT ---APPLICATION --

METALS -----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBIENT

M-OIL-FREE CO. ULTRA 1

INGREDIENT ---APPLICATION --METALS -----JOHN HAS MORE DATA

TEMPERATURE 'F SUGGESTED CONCENTRATIONS NO SUGGESTED CONCENTRATION M-OIL-FREE CO. ULTRA 70 INGREDIENT ---APPLICATION --METALS ----SUGGESTED CONCENTRATIONS TEMPERATURE 'F CONCENTRATE AMBIENT M-OIL-FREE CO. ULTRA 90 INGREDIENT ---APPLICATION --METALS -----

TEMPERATURE 'F

AMBIENT

SUGGESTED CONCENTRATIONS

CONCENTRATE

MAGNUSON PRODUCTS

PERMAG #404

INGREDIENT --- SODIUM HYDROXIDE APPLICATION -- OIL, GREASE, CARBON METALS ----- FERROUS METALS NOT FOR NONFERROUS METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 6 OZ/GAL | 160 |
| 12 OZ/GAL | 160 |

MAN-GILL CHEMICAL

MAGNUSOL 728

INGREDIENT --- PETROLEUM NAPTHA, 2-BUTOXYETHANOL, DODECYL BENZENE, SULFO ACID, POTASSIUM HYDROXIDE, CYCLOHEXANOL

APPLICATION -- GREASE, OIL, CARBON

METALS ---- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1-4 | AMBEINT |

MEASURY COL.

MYCO

INGREDIENT --APPLICATION -METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

MEQQEM

MEQQEM-CLEAN 8512

INGREDIENT --- ALKALINE APPLICATION -- GREASE

METALS ----- STEEL, Cu, BRASS, Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 2% | 40 |
| 2% | 60 |
| 2% | 90 |
| 5% | 40 |
| 5% | 60 |
| 5% | 90 |
| 10% | 40 |
| 10% | 60 |
| 10% | 90 |

MEQQEM

MEQQEM-CLEAN 8516

INGREDIENT --- ACID
APPLICATION -- GREASE

METALS ----- Al, BRASS, STEEL

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 2% | 20 |
| 2% | 40 |
| 2% | 60 |
| 5% | 20 |
| 5% | 40 |
| - 5% | 60 |
| | |

MIRACHEM

MIRACHEM 100

INGREDIENT --- detergents, emulsifiers, C9-C12 hydrocarbons APPLICATION -- GREASE, OIL, WAX, CARBON METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE *F |
|--------------------------|----------------|
| 3:1 | AMBEINT |
| 3:1 | 180 |
| | |

MITCHELL-BRADFORD, INTERNMI-CLEAN 100

INGREDIENT --- SODIUM HYDROXIDE
APPLICATION -- OIL, GREASE
METALS ----- ALL METALS
NOT FOR Fe, BRONZE, Cu, Sn, NOT Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE 'F |
|--------------------------|----------------|
| 6 OZ/GAL | 65 |
| 6 OZ/GAL | 100 |
| 6 OZ/GAL | 160 |
| 8 OZ/GAL | 65 |
| · 8 OZ/GAL | 100 |
| 8 OZ/GAL | 160 |
| 10 OZ/GAL | 65 |
| 10 OZ/GAL | 100 |
| 10 OZ/GAL | 160 |
| | |

MITCHELL-BRADFORD, INTERNMI-CLEAN 14

INGREDIENT --- SODIUM METASILICATE

APPLICATION -- CLEANER METALS ----- STEEL, Cu

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 8 OZ/GAL | 180 |
| 10 OZ/GAL | 180 |

MITCHELL-BRADFORD, INTERNMI-CLEAN 31

INGREDIENT --- SODIUM HYDROXIDE

APPLICATION -- OIL, GREASE, METAL OXIDES

METALS ----- ALL METALS

NOT Al

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 6 OZ/GAL | 160 |
| 10 OZ/GAL | 160 |
| 16 OZ/GAL | 160 |

MITCHELL-BRADFORD, INTERNMI-CLEAN 59

INGREDIENT --- SODIUM TRIPOLYPHOSPHATE, TETRASODIUM PYROPHOSPHATE

APPLICATION -- CLEANER

METALS ----- Al

| SUGGESTED | CONCENTRATIONS | TEMPERATURE | • F |
|-----------|----------------|-------------|-----|
| 6 | OZ/GAL | 130 | - |
| 6 | OZ/GAL | 160 | |
| 8 | OZ/GAL | 130 | |
| 8 | OZ/GAL | 160 | |
| | | | |

OAKITE PRODUCTS INC. OAKITE 162

INGREDIENT --- sodium cabonate, sodium hydroxide, sodium metasilicate APPLICATION -- CLEANING MIXED METALS METALS ----- STEEL, Cu, BRASS, BRONZE

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4 OZ/GAL | 120 |
| 4 OZ/GAL | 180 |
| 4 OZ/GAL | 150 |
| 8 OZ/GAL | 120 |
| 8 OZ/GAL | 180 |
| 8 OZ/GAL | 150 |
| 10 OZ/GAL | 120 |
| 10 OZ/GAL | 180 |
| 10 OZ/GAL | 150 |

OAKITE PRODUCTS INC.

OAKITE 2327

INGREDIENT --- sodium carbonate, sodium metasilicate, sodium hydroxide d rosin, hexylene glycol,

APPLICATION -- OIL, GREASE

METALS ----- Cu, BRASS, BRONZE, Zn, Sn, FERROUS METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4 OZ/GAL | 160 |
| 4 OZ/GAL | 180 |
| 4 OZ/GAL | 200 |
| 8 OZ/GAL | 160 |
| 8 OZ/GAL | 180 |
| 8 OZ/GAL | 200 |

OAKITE PRODUCTS INC.

OAKITE 24

INGREDIENT --- sodium metasilicate, sodium hydroxide, sodium carbonate APPLICATION -- OILS, GREASE BASED SOLIDS METALS ----- STEEL, Cu, BRASS

| °F |
|----|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |

OAKITE PRODUCTS INC. OAKITE ANOPREP

INGREDIENT --- sodium metasilicate, sodium hydroxide, sodium carbonate ium tripoly phosphate,

APPLICATION -- SHOP SOILS METALS ----- STEEL, Cu

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 2 OZ/GAL | 100 |
| 2 OZ/GAL | 130 |
| 2 OZ/GAL | 160 |
| 5 OZ/GAL | 100 |
| 5 OZ/GAL | 130 |
| 5 OZ/GAL | 160 |
| 8 OZ/GAL | 100 |
| 8 OZ/GAL | 130 |
| 8 OZ/GAL | 160 |

OAKITE PRODUCTS INC. OAKITE DYNADET

INGREDIENT --- sodium hydroxide, tetrasodium polyethoxyethanol, dipent APPLICATION -- CLEANING BEFORE ELECTROPLATING METALS ----- STEEL, SS, Mg

| | SUGGESTED | CONCENTRATIONS | TEMPERATURE | ° F |
|---|-----------|----------------|-----------------|-----|
| - | | | | |
| | | | | |

OAKITE PRODUCTS INC. OAKITE HD 126

INGREDIENT --- sodium hydroxide, sodium carbonate, tetrasodium pyropho e, ethoxylated amphoteric sodium salt,

APPLICATION -- HEAVY DUTY CLEANER

METALS ----- STEEL, SS,MG

NOT FOR Al, Zn, OR BRASS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 4 OZ/GAL | 170 C |
| 4 OZ/GAL | 190 C |
| 7 OZ/GAL | 170 C |
| 7 OZ ['] /GAL | 190 C |
| 10 OZ/GAL | 170 C |
| 10 OZ/GAL | 190 C |

OAKITE PRODUCTS INC. RUST STRIPPER

INGREDIENT ---APPLICATION --METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE "F

NO SUGGESTED CONCENTRATION

ORANGE-SOL INCORPERATED DE-SOLV-IT

INGREDIENT --- PETROLEUM DISTALLATE

APPLICATION -- OIL, GREASE, WAX

METALS ----- ALL METALS

SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT

P ·D-680

INGREDIENT ---APPLICATION --METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

PACIFIC CHEMICAL B-82

INGREDIENT ---APPLICATION --METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F ,

PACIFIC CHEMICAL FIST

INGREDIENT ---

APPLICATION -- OIL, GREASE

METALS ---- ALL

SUGGESTED CONCENTRATIONS

TEMPERATURE 'F

2 OZ/GAL 4 OZ/GAL 6 OZ/GAL

AMBIENT AMBIENT AMBIENT

PACIFIC CHEMICAL MASTER MHW

INGREDIENT --- SODIUM SILICATE, SODIUM CARBONATE APPLICATION --METALS ----- Al, IRON, TIN BRUSH OR GUN APPLICATION

> SUGGESTED CONCENTRATIONS TEMPERATURE °F 1 OZ/GAL AMBIENT

PACIFIC CHEMICAL PACE S-L

INGREDIENT --- SODIUM METASILICATE, SODIUM CARBONATE APPLICATION -- OILS METALS ----- ALL

> SUGGESTED CONCENTRATIONS TEMPERATURE °F 2 OZ/GAL AMBIENT 3 OZ/GAL AMBIENT

PACIFIC CHEMICAL RIDDALL

INGREDIENT --- SODIUM METASILICATE, ETHYLENE, GLYCOL, N.BUTYL ETHER APPLICATION -- GREASE, OIL, WAX METALS ---- ALL BRUSH APPLICATION

SUGGESTED CONCENTRATIONS TEMPERATURE 'F 1:4 AMBIENT

PANTHER CHEMICAL CO. 759

INGREDIENT ---APPLICATION -- OIL, WAX METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

PANTHER CHEMICAL CO. AS-33

INGREDIENT --- SODIUM HYDROXIDE APPLICATION -- OILS, GREASE, PAINT METALS ---- FERROUS METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1 OZ/GAL | 180 F |
| 1 OZ/GAL | 200 F |
| 4 OZ/GAL | 180 F |
| 4 OZ/GAL | 200 F |

PANTHER CHEMICAL CO. CR-138

INGREDIENT --- CRESYLIC ACID

APPLICATION -- OIL, GREASE, PAINT, CARBON

METALS ----- ALL METALS

TWO PHASE, MIX WELL BEFORE USE

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |

PANTHER CHEMICAL CO. CR-140

INGREDIENT --- CRESYLIC ACID

APPLICATION -- OIL, GREASE, PAINT, CARBON

METALS ----- ALL METALS

TWO PHASE, MIX WELL BEFORE USING

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |

PANTHER CHEMICAL CO. RR 50

INGREDIENT --- SODIUM HYDROXIDE

APPLICATION -- OIL, GREASE, RUST, PAINT

METALS ----- FERROUS METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1.5 LB/GAL | 180 F |
| 1.5 LB/GAL | 200 F |

PARKER CHEMICAL PARCO CLEANER 2033

INGREDIENT --- MILD ALKOLINE APPLICATION --ETALS ----- STEEL, Al

> SUGGESTED CONCENTRATIONS TEMPERATURE °F

PARKER CHEMICAL PARCO CLEANER 2053

INGREDIENT --- STRONG ALKALINE

APPLICATION --

METALS ----- STEEL

SUGGESTED CONCENTRATIONS TEMPERATURE 'F

PATCLIN CHEMICAL CO. #309

INGREDIENT --- SODIUM HYDROXIDE

APPLICATION -- OIL, GREASE

METALS ----- BRASS, Cu, STEEL, Mg

| SUGGESTED (| CONCENTRATIONS | TEMPERATURE °F |
|-------------|----------------|----------------|
| 6 | OZ/GAL | 150 |
| 6 | OZ/GAL | 170 |
| 6 | OZ/GAL | 210 |
| 9 | OZ/GAL | 150 |
| 9 | OZ/GAL | 170 |
| 9 | OZ/GAL | 210 |
| 12 | OZ/GAL | 150 |
| 12 | OZ/GAL | . 170 |
| 12 | OZ/GAL | 210 |
| 12 | OZ/GAL | 210 |

PATCLIN CHEMICAL CO. #348

INGREDIENT --- SODIUM HYDROXIDE APPLICATION -- OIL, GREASE METALS ----- STEEL, Mg, Cu

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 8 OZ/GAL | 150 |
| 8 OZ/GAL | 180 |
| 8 OZ/GAL | 210 |
| 10 OZ/GAL | 150 |
| 10 OZ/GAL | 180 |
| 10 OZ/GAL | 210 |
| 12 OZ/GAL | 150 |
| 12 OZ/GAL | 180 |
| 12 OZ/GAL | 210 |

PATCLIN CHEMICAL CO. #380

INGREDIENT --- SODIUM HYDROXIDE

APPLICATION -- SCALE METALS ----- STEEL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 1 Lbs/GAL | AMBIENT |
| 1 Lbs/GAL | 100 |
| 1 Lbs/GAL | 200 |
| 3 Lbs/GAL | AMBIENT |
| 3 Lbs/GAL | 100 |
| 3 Lbs/GAL | 200 |
| · | |

PATCLIN CHEMICAL CO. #490

INGREDIENT --- DIETHYLENE GLYCOL MONOBUTYL ETHER

APPLICATION -- GREASE, OIL

METALS ----- ALL

| SUGGESTED | CONCENTRATIONS |
|-----------|----------------|
| | |

TEMPERATURE °F

1:4 1:10 AMBIENT AMBIENT

PATCLIN CHEMICAL CO. 359

INGREDIENT ---

APPLICATION --

METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

PATCLIN CHEMICAL CO. 396

INGREDIENT ---

APPLICATION --

METALS ----

SUGGESTED CONCENTRATIONS TEMPERATURE °F

NO SUGGESTED CONCENTRATION

PATCLIN CHEMICAL CO. 73W INGREDIENT ---APPLICATION --METALS -----SUGGESTED CONCENTRATIONS TEMPERATURE 'F NO SUGGESTED CONCENTRATION PATCLIN CHEMICAL CO. PATCLIN INGREDIENT ---APPLICATION -- 73W METALS ----JOHN HAS MORE DATA SUGGESTED CONCENTRATIONS TEMPERATURE °F NO SUGGESTED CONCENTRATION PENETONE CITRI KLEEN INGREDIENT --- ETHANOLAMINE APPLICATION -- OIL, GREASE, CARBON METALS ----

SUGGESTED CONCENTRATIONS

NO SUGGESTED CONCENTRATION

TEMPERATURE °F

PETROFIRM INC. BIOACT INDUSTRIAL DG1

INGREDIENT --- TERPENE HYDROCARBONS

APPLICATION -- OIL, GREASE

METALS ---- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| CONCENTRATE | AMBIENT |
| 75% | AMBIENT |

PHENOL

PHENOL

INGREDIENT ---APPLICATION --METALS -----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

PROGRESS CHEMICAL INC. #611

INGREDIENT --- ALKALINE APPLICATION -- CLEANER

METALS ----- NON-FERROUS METALS

SUGGESTED CONCENTRATIONS TEMPERATURE °F 1.0 OZ/GAL AMBIENT 2.5 OZ/GAL AMBIENT 4.0 OZ/GAL AMBIENT

PROGRESS CHEMICAL INC. #65

INGREDIENT --- ALKALINE APPLICATION -- CLEANING

METALS ----- FERROUS AND NON FERROUS METALS

| SUGGESTED | CONCENTRATIONS | TEMPERATURE | °F |
|-----------|----------------|-------------|----|
| 1 | OZ/GAL | AMBIENT | |
| 2 | OZ/GAL | AMBIENT | |
| 3 | OZ/GAL | AMBIENT | |

PROGRESS CHEMICAL INC. AC-1

INGREDIENT --- SURFACTANTS APPLICATION -- CLEANING

METALS ----- Al

| SUGGESTED | CONCENTRATIONS | TEMPERATURE °F |
|-----------|----------------|----------------|
| 4 | OZ/GAL | 150 |
| | OZ/GAL | 180 |
| 6 | OZ/GAL | 150 |
| 6 | OZ/GAL | 180 |
| 8 | OZ/GAL | 150 |
| 8 | OZ/GAL | 180 |

PROGRESS CHEMICAL INC. L-365

INGREDIENT --- POTASSIUM HYDROXIDE

APPLICATION -- CLEANING

METALS ----- FERROUS AND NON FERROUS METALS

| | SUGGESTED | CONCENTRATIONS | TEMPERATURE | °F | |
|---|-----------|----------------------------|-------------------------------|----|--|
| - | 2 | OZ/GAL OZ/GAL OZ/GAL | AMBIENT AMBIENT AMBIENT | | |
| _ | | | | | |

ROCHESTER MIDLAND

SE-354

INGREDIENT ---APPLICATION --METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

ROCHESTER MIDLAND SE-358

INGREDIENT ---APPLICATION --METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE 'F

NO SUGGESTED CONCENTRATION

ROCHESTER MIDLAND SE-374

INGREDIENT ---APPLICATION --METALS -----

SUGGESTED CONCENTRATIONS TEMPERATURE 'F

NO SUGGESTED CONCENTRATION

ROCHESTER MIDLAND SE377C

INGREDIENT --- D-LIMONENE

APPLICATION -- OIL, GREASE, FATS

METALS ----- ALL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|--------------------|
| 1:2 | AMBIENT |
| 1:4 1:7 | AMBIENT AMBIENT |

SIMPLE GREEN

GREEN

INGREDIENT ---APPLICATION --METALS ----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

SUTTON CORP. TOPSALL

INGREDIENT --- DETERGENT APPLICATION -- OIL, GREASE METALS ----- ALL NOT Al

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

1-5 AMBEINT TELSTAR INDUSTRIES TELE-SOLV

INGREDIENT --- GLYCOL ETHER BUTYL CELLUSOLVE, POTASSIUM HYDROXIDE

APPLICATION -- GREASE, OIL,

METALS ----- ALL

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

1:2 1:10 AMBEINT AMBEINT

TITAN CHEMICAL

OIL-FLO

INGREDIENT --- AROMATIC HYDROCARBON

APPLICATION -- OIL, GREASE,

METALS ----- ALL

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBEINT

TITAN GOLD

GOLD

INGREDIENT ---

APPLICATION --

METALS -----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

TRI TON

HEMO-SOL

INGREDIENT --- 4-ISOPROPENYL-1-METHYLCYCLOHEXENE APPLICATION -- OIL, GREASE, WAX METALS ----- ALL FLASHE POINT OF 115 F

| | SUGGESTED CONCENTRATIONS | TEMPERATURE 'F | |
|--------------|---|---------------------------|-------------|
| | CONCENTRATE | AMBIENT | |
| INGR APPL | ROETHANE TRICHLOROETH EDIENT ICATION LS | ANF | |
| | SUGGESTED CONCENTRATIONS | TEMPERATURE °F | |
| | NO SUGGESTED CONCENTRATION | | |
| TWIN SP | ECIALTIES CORP. CLEANER 54-T | WIN INDUSTRIA | |
| APPL | EDIENT POTASSIUM HYDROXIDE ICATION OIL, GREASE, SOIL LS | , GLYCOL ETHER BLEND, SOD | IUM SILCATE |
| | SUGGESTED CONCENTRATIONS | TEMPERATURE °F | |
| | 1:3 1:5 | AMBIENT AMBIENT | |

INGREDIENT --- CITRUS TERPENES & SURFACTANTS APPLICATION -- DEGREASER METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT U.S. POLYCHEMICAL CORP. ST-21 POLY SPRAY JET INGREDIENT --- ETHYLENE GLYCOL MONO BUTYL ETHER ISOPROPYL ALCOHOL APPLICATION -- CUTTING OILS, DEGREASING, WAX METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F 1:10 AMBIENT 1:12 160 UNITED LABORATORIES UNITED 392 INGREDIENT --- d-1,8(9)-p-MENTHADIENE APPLICATION -- GREASE, OIL METALS ----- ALL SUGGESTED CONCENTRATIONS TEMPERATURE °F CONCENTRATE AMBIENT

TWIN SPECIALTIES CORP. TWIN CITRON CLEANER 100

UNITED LABORATORIES UNITED 395

INGREDIENT --- d-1,8(9)-p-MENTHADIENE

APPLICATION -- GREASE, OIL

METALS ----- ALL

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

CONCENTRATE

AMBIENT

VAN STRAATEN CHEM CO. 21-271-A

INGREDIENT --- TRIETHANOLAMINE

APPLICATION -- NEUTRAL SOAK CLEANER

METALS ----- ALUMINUM AND 7000 SERIES ALLOYS

| TEMPERATURE °F |
|----------------|
| AMBIENT |
| 100 |
| 180 |
| AMBIENT |
| 100 |
| . 180 |
| AMBIENT |
| 100 |
| 180 |
| |

VAN STRAATEN CHEM CO. 3625

•

INGREDIENT --- MONOETHANOLAMINE 5-10%, POTASIUM HYDROXIDE 5-10% APPLICATION -- SPRAY & SOAK CLEANER METALS ----- COMMON INDUSTRIAL METALS

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F | | |
|--------------------------|----------------|--|--|
| 1.0 OZ/GAL | AMBIENT | | |
| 1.0 OZ/GAL | 100 | | |
| 1.0 OZ/GAL | 180 | | |
| 2.5 OZ/GAL | AMBIENT | | |
| 2.5 OZ/GAL | 100 | | |
| 2.5 OZ/GAL | 180 | | |
| 4.0 OZ/GAL | AMBIENT | | |
| 4.0 OZ/GAL | 100 | | |
| 4.0 OZ/GAL | 180 | | |

VAN STRAATEN CHEM CO. VANSTAATEN CUTTER

INGREDIENT --- POTASSIUM HYDROXIDE
APPLICATION -- FLOORS, MACHINERY AND PRODUCTION PARTS
METALS ----- ANY SURFACE NOT HARMED BY WATER

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 18 | - AMBIENT |
| 28 | AMBIENT |

ZEP MANUFACTURING CO. BIG ORANGE

INGREDIENT --- D-LIMONENE, NONYLPHENOXYPOLY ETHANOL APPLICATION -- OIL, GREASE METALS ----- ALL

| SUGGESTED CONCENTRATIONS | TEMPERATURE °F |
|--------------------------|----------------|
| 2 OZ/GAL | AMBIENT |
| CONCENTRATE | AMBIENT |

ZEP MANUFACTURING CO. PENETONE

INGREDIENT --APPLICATION -METALS -----

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

NO SUGGESTED CONCENTRATION

ZEP MANUFACTURING CO. ZEP 940

INGREDIENT --- SODIUM METASILICATE APPLICATION -- OILS, GREASE, WAX METALS ----- FERROUS METALS NOT SOFT METALS

SUGGESTED CONCENTRATIONS

TEMPERATURE °F

4 OZ/GAL 8 OZ/GAL 12 OZ/GAL

AMBIENT AMBIENT

APPENDIX E

SOLVATION TEMPERATURES

These tables contain the solvation temperature for each solvent. It was established as the temperature at which a 0.5-gram sample of masking wax was dissolved in the solvent.

TABLE E-1. BIODEGRADABLE SOLVENTS SOLVANTION TEMPERATURE POINTS

| Company | Product | Degrees F Concentration |
|--------------------------|---|---|
| 3 D INC. | 3D SUPREME CITRIGOLD SIEGE | 72 1:3 72 1:1 72 1:4 |
| BARTLETT CHEMICAL INC. | DOLPHIN TPS CODE 219 DOLPHIN WSD CODE 207 TOBY CODE 230 | 72 1:10 72 4 0Z/GAL 80 1:3 |
| BIO-TEK INC. | 134 HI-SOLV SAFTEY SOLVENT DEGREASER | 72 CONCENTRATE 72 CONCENTRATE |
| BRULIN | 711 SC 815 QR AQUA SAFE CL-500 FORMULA 512M NATURE-SOL 100 | 72 1:3 89 1:10 72 1:5 160 8 OZ/GAL 72 1:4 72 CONCENTRATE |
| BUILD ALL | BAC #137 | 115 10% |
| CABOT CHEMICAL CORP. | X-166 | 200 1:20 >200 |
| CALLA CHEMICAL CORP. | CALLA 301-A | 72 1:1 72 1:1 72 1:1 72 CONCENTRATE |
| CROWLEY CHEMICAL COMPANY | METHYL NAPHTHALENE #5 | 72 CONCENTRATE |
| DOBER CHEMICAL CORP. | 4190 8679 | 72 1:20 80 16 OZ/GAL |
| DREW INDUSTRIAL DIVISION | DREW OIL AND GREASE REM. | 72 CONCENTRATE |
| ELGENE CHEMICALS INC. | #22 SKIDOO A-CD ECONOMISER CF | 100 1:5 120 1:5 72 CONCENTRATE |
| EXXON CHEMICALS | EXXATE 1000 EXXATE 1300 EXXATE 600 EXXATE 700 EXXATE 800 | 72 CONCENTRATE 72 CONCENTRATE 72 CONCENTRATE 72 CONCENTRATE 72 CONCENTRATE 72 CONCENTRATE |
| FORMULA IV CORPORATION | MAGNA IV C-1000 | 200 1:10 >200 |
| FREDERICK GUMM CHEM. | CLEPO 136-R CLEPO 204 CLEPO 644-L SONIC SOAK | 72 8 OZ/GAL 200 8 OZ/GAL >200 72 6% NOT VISIBLE 72 3% |

TABLE E-1. BIODEGRADABLE SOLVENTS SOLVANTION TEMPERATURE POINTS (CONTNIUED)

| Company | Product | Degrees F Concentration |
|---|--|--|
| GRAYMILLS CORP. | AQUATENE 330 AQUATENE 571 AQUATENE 581 | 72 1:4 124 8 OZ/GAL 168 20 OZ/GAL |
| HOLT LLOYD CORP. | CHEMPRO APC | 72 1:2 |
| HOMESTEAD INDUSTRIES INC | #49 #49-S #65 AP HDL | 165 19 OZ/GAL 200 19 OZ/GAL 200 1:250 >200 72 12 OZ/GAL 200 1:250 >200 |
| HUNTINGTON | LHTS ONLINE CE SD THUNDER BOLT | 85 6 OZ/GAL 72 CONCENTRATE 72 1:2 |
| HYDRITE CHEMICAL CO. | HYDRI-CLEAN NPX | 72 1:1 |
| INTERNATIONAL PRODUCTS CO | MICRO | 200 2 OZ/GAL >200 |
| JOHNSON WAX/GEM STATE PAP KIESOW INTERNATIONAL CORP | BIG BARE J-SHOP 500 J-SHOP 600 EKASIT D-103 EKASIT E-231 EKASIT S-261 | 92 1:15 72 1:4 72 1:10 200 30 OZ/GAL >200 153 8 OZ/GAL 124 8 OZ/GAL |
| LAKE PRODUCTS CO. INC. | LAKE-97 | 72 1:7 |
| LEA MANUFACTURING CO. | CLEANOL | 108 2 OZ/GAL |
| MAGNUSON PRODUCTS | PERMAG #404 | 72 12 OZ/GAL |
| MEQQEM | MEQQEM-CLEAN 8512 MEQQEM-CLEAN 8516 | 142 10% 145 5% |
| MITCHELL-BRADFORD, INTERN | MI-CLEAN 100 MI-CLEAN 14 MI-CLEAN 31 MI-CLEAN 59 | 125 10 OZ/GAL 82 10 OZ/GAL 128 16 OZ/GAL 80 8 OZ/GAL |
| OAKITE PRODUCTS INC. | OAKITE 162 OAKITE 2327 OAKITE 24 OAKITE ANOPREP OAKITE DYNADET OAKITE HD 126 | 104 10 OZ/GAL 89 8 OZ/GAL 72 10 OZ/GAL 92 8 OZ/GAL 90 8 OZ/GAL 72 10 OZ/GAL |

TABLE E-1. BIODEGRADABLE SOLVENTS SOLVANTION TEMPERATURE POINTS (CONTNIUED)

| Company | Product | Degrees F Concentration | |
|-------------------------|---|--|--|
| ORANGE-SOL INCORPERATED | DE-SOLV-IT | 72 CONCENTRATE | |
| PACIFIC CHEMICAL | FIST MASTER MHW PACE S-L RIDDALL | 90 6 OZ/GAL 108 10 OZ/GAL 100 3 OZ/GAL 72 1:4 | |
| PANTHER CHEMICAL CO. | AS-33 RR 50 | 89 4 OZ/GAL 85 1.5 LB/GAL | |
| PARKER CHEMICAL | PARCO CLEANER 2033 PARCO CLEANER 2053 | 85 8 OZ/GAL 78 8 OZ/GAL | |
| PATCLIN CHEMICAL CO. | #309 #348 | 89 12 07/GAL 91 12 07/GAL | |
| | #380 #490 | 200 3 LBS/GAL >200 72 1:4 | |
| PETROFIRM INC. | BIOACT INDUSTRIAL DG1 | 72 CONCENTRATE | |
| PROGRESS CHEMICAL INC. | #611 #65 L-365 | 98 4 OZ/GAL 109 3 OZ/GAL 72 1:3 | |
| ROCHESTER MIDLAND | SE377C | 72 1:2 | |
| U.S. POLYCHEMICAL CORP. | ST-21 POLY SPRAY JET | 86 1:10 | |
| VAN STRAATEN CHEM CO. | 21-271-A | 200 10 OZ/GAL >200 | |
| ZEP MANUFACTURING CO. | BIG ORANGE . ZEP 940 ZEPRIDE | 72 CONCENTRATE 91 12 OZ/GAL 72 1:3 | |

APPENDIX F

SOLUBILITY DATA

APPENDIX F

SOLUBILITY DATA

These tables contain the data on solubility of masking wax in each solvent. They were established using McCoy's Method.

BIODEGRADABLE SOLVENT PROGRAM SOLUBILITY TESTS

| Company Product | | Cor | nditions | | Solubility |
|--|---|-----|-------------------|--|------------|
| 3 D INC. 3D SUPREME | 1-3 | 9 | 180 | 1% | |
| 3 D INC. CITRIGOLD | CONCENT CONCENT CONCENT 1:1 1:1 | 000 | 160 | 18% 24% 88% 35% 49% 88% | • |
| 3 D INC. SIEGE | 1:4 | 9 | 160 | 0% | |
| BIO-TEK INC. 134 HI-SOLV | CONCENT CONCENT | | AMBIENT 140 | 15% 20% | |
| BIO-TEK INC. SAFTEY SOLVENT DEGREASER | CONCENT CONCENT | | AMBIENT 140 | 12% 79% | |
| BRULIN AQUA SAFE | 1:5 1:10 | | 160 160 | 0% 0% | |
| BRULIN NATURE-SOL 100 | CONCENT CONCENT CONCENT | 0 | AMBIENT | 31% 0% 97% | |
| CALLA CHEMICAL CORP CALLA 301-A-LEMON | 1:4 1:1 CONCENT | 6 | 120 100 140 | 0% 0% 0% | |
| CROWLEY CHEMICAL COMPANY METHYL NAPHTHALENE #5 | CONCENT | @ | AMBIENT | 12% | |
| DOBER CHEMICAL CORP. 8679 | 4 OZ/GA 16 OZ/G | | | 11% 0% | |
| DREW INDUSTRIAL DIVISION DREW OIL AND GREASE REM. | CONCENT | @ | AMBIENT | 4% | |
| ELGENE CHEMICALS INC. ECONOMISER CF | CONENTR CONCENT | | AMBIENT 140 | 0% 0% | |
| ELGENE CHEMICALS INC. FABULENE | 1:2 | 0 | 160 | 1% | · |

BIODEGRADABLE SOLVENT PROGRAM SOLUBILITY TESTS (CONTINUED)

| Company Product | Cor | nditions | | ubility |
|--|-------------------------------------|----------------------------------|-----------------------|---------|
| EXXON CHEMICALS EXXATE 1000 | CONCENT @ CONCENT @ CONCENT @ | 100 | 14% 49% 95% | |
| EXXON CHEMICALS EXXATE 1300 | CONCENT @ | | 6% 78% | |
| EXXON CHEMICALS EXXATE 600 | CONCENT @ CONCENT @ CONCENT @ | 100 | 14% 92% 91% | |
| EXXON CHEMICALS EXXATE 700 | CONCENT @ CONCENT @ CONCENT @ | 100 | 9% 40% 99% | |
| EXXON CHEMICALS EXXATE 800 | CONCENT @ | | 5% 95% | |
| EXXON CHEMICALS EXXATE 900 | CONCENT @ | | 5% 84% | |
| FORMULA IV CORPORATION MAGNA IV C-1000 | 1:10 @ 1:10 @ | AMBIENT AMBIENT 100 140 | 0% 0% 0% 99% | |
| GRAYMILLS CORP. AQUATENE 330 | | 150 180 | 21% 31% | |
| GRAYMILLS CORP. AQUATENE 571 | 8 OZ/GA @ | 180 | 0% | |
| GRAYMILLS CORP. AQUATENE 581 | 20 OZ/G @ | 200 | 8% | |
| HOLT LLOYD CORP. CHEMPRO APC | 1:2 @ | AMBIENT 140 140 | 1% 0% 0% | |

BIODEGRADABLE SOLVENT PROGRAM SOLUBILITY TESTS (CONTINUED)

| Company Product | Conditions | Solubility |
|--|--|----------------------|
| OMESTEAD INDUSTRIES INC.#49-S | 19 OZ/G @ AMBIENT 19 OZ/G @ 140 | 0% 0% |
| OMESTEAD INDUSTRIES .INC.#65 | 1:250 @ AMBIENT 1:250 @ 140 | 0% 0% |
| YDRITE CHEMICAL CO. HYDRI-CLEAN NPX | 1:1 @ 100 1:1 @ 130 | 20% 87% |
| YLUBE INC. HYKLEEN 300 | CONCENT @ AMBIENT 1:4 @ AMBIENT CONCENT @ 140 | 0% 0% 0% |
| NTERNATIONAL PRODUCTS COMICRO | 2 OZ/GA @ 200 | 0% |
| RANGE-SOL INCORPERATED DE-SOLV-IT | CONCENT @ AMBIENT CONCENT @ 100 CONCENT @ 140 | 18% 60% 99% |
| ACIFIC CHEMICAL RIDDALL | 1:4 @ AMBIENT 1:4 @ 140 | 0% 3% |
| ATCLIN CHEMICAL CO. #490 | 1:4 @ AMBIENT 1.4 @ 140 | 3% 19% |
| ETROFIRM INC. BIOACT INDUSTRIAL DG1 | CONCENT @ AMBIENT CONCENT @ CONCENT @ 140 | 20% 0% 97% |
| OCHESTER MIDLAND SE377C | 1:2 @ AMBIENT 1:2 @ 140 1:4 @ 140 | 13% 32% 44% |
| .S. POLYCHEMICAL CORP. ST-21 POLY SPRAY JET | 1:10 @ AMBIENT | 0% |
| AN STRAATEN CHEM CO. 21-271-A | 6 OZ/G @ AMBIENT 10 OZ/G @ 180 2 OZ/G @ 180 10 OZ/G @ 100 | 4% 0% 4% 0% |

BIODEGRADABLE SOLVENT PROGRAM SOLUBILITY TESTS (CONTINUED)

| Conditions | Solubility |
|-------------------|--|
| | |
| CONCENT @ AMBIENT | 40% |
| CONCENT @ 140 | 83% |
| 2 OZ/GA @ 140 | 2% |
| | |
| 4 OZ/GA @ AMBIENT | 0% |
| | 0% |
| | 0% |
| 12 OZ/G @ 100 | C% |
| 12 OZ/G @ 140 | 0% |
| | |
| 1:3 @ 160 | 0% |
| 1:5 @ 160 | 1% |
| | CONCENT @ AMBIENT CONCENT @ 140 2 OZ/GA @ 140 4 OZ/GA @ AMBIENT 8 OZ/GA @ AMBIENT 12 OZ/G @ AMBIENT 12 OZ/G @ 100 12 OZ/G @ 140 |